VGN-A51PS1/A51PS2/A51S1/A51S2/A61B/A71PS/A71S VGN-A230/A230B/A230P/A240/A240B/A240P/A250/A260/A270/A270B/A270P/A290/A290F VGN-A215M/A215Z/A217M/A217S/A295HP/A297XP VGN-A21C/A23CP/A29CP/A29GP/A29LP/A29SP/A29TP

SERVICE MANUAL

Ver 5 -2004L

Revision History

Area	Model	Line up	1
Japanese	Japanese	VGN-A51PS1*	<u> </u>
		VGN-A51PS2*	<u> </u>
		VGN-A51S1*	<u> </u>
		VGN-A51S2*	<u> </u>
		VGN-A61B	<u> </u>
		VGN-A71PS*	<u> </u>
		VGN-A71S*	<u> </u>
American	US	VGN-A230*	<u></u> (MA)
	Canadian	VGN-A230B*	<u></u> (MA)
		VGN-A230P*	<u> </u>
		VGN-A240*	<u></u> (MA)
		VGN-A240B*	<u></u> (MA)
		VGN-A240P*	<u></u> (MA)
		VGN-A250	<u> </u>
		VGN-A260	<u></u> [MA]
		VGN-A270*	<u> </u>
		VGN-A270B*	<u></u> (MA)
		VGN-A270P*	<u></u> (MA)
		VGN-A290	
	Latin	VGN-A290F	<u> </u>
European	AEP	VGN-A215M	<u> </u>
	UK	VGN-A215Z	<u> </u>
		VGN-A217M	<u></u> (MA)
		VGN-A217S	<u> </u>
		VGN-295HP	<u> </u>
		VGN-297XP	<u>∧</u> [MA]
Asian/Oceania/	International	VGN-A29GP	<u> </u>
South Africa	Thai	VGN-A29SP	<u> </u>
	Korean	VGN-A29LP	▲[MA]
	China	VGN-A21C	<u></u> ∆ [MA]
		VGN-A23CP	<u></u> ∆ [MA]
		VGN-A29CP	<u></u> ♠ [MA]
	Thaiwan	VGN-A29TP	<u></u> ≰[MA]













- Design and specifications are subject to change without notice.
- 本機の仕様および外観は、改良のため予告なく変更 することがありますが、ご了承ください。

PERSONAL COMPUTER



Information in this document is subject to change without notice.

Sony, VAIO and CLIE are trademarks or registered trademarks of Sony. Microsoft, Windows, Windows Media, Outlook, Bookshelf and other Microsoft products are trademarks or registered trademarks

of Microsoft Corporation in the United States and other countries.

The word Bluetooth and the Bluetooth logo are trademarks of Bluetooth SIG, Inc. AMD, AMD logo, AMD Duron and combinations thereof. 3DNow!, are trademarks of Advanced Micro Devices, Inc. Intel Inside logo, Pentium and Celeron are trademarks or registered trademarks of Intel Corporation. Transmeta, the Transmeta logo, Crusoe Processor, the Crusoe logo and combinations thereof are trademarks of Transmeta Corporation in the USA and other countries. Graffiti, HotSync, PalmModem, and Palm OS are resistered trademarks, and the Hotsync logo and Palm are trademarks of Palm, Inc. or its subsidiaries. (M) and Motrola are trademarks of Motrora, Inc. Other Motrola products and services with (R) mark like Dragomball are the trademarks of Motrola, Inc.

All other names of systems, products and services in this manual are trademarks or registered trademarks of their respective owners.

In this manual, the (TM) or (R) mark are not specified.

Caution Markings for Lithium/Ion Battery - The following or similar texts shall be provided on battery pack of equipment or in both the operating and the service instructions.

CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

CAUTION: The battery pack used in this device may present a fire or chemical burn hazard if mistreated. Do not disassemble, heat above 100°C (212°F) or incinerate.

Dispose of used battery promptly. Keep away from children.

CAUTION: Changing the back up battery.

- Overcharging, short circuiting, reverse charging, multilation or incineration of the cells must be avoided to prevent one or more of the following occurrences; release of toxic materials, release of hydrogen and/or oxygen gas, rise in surface temperature.
- If a cell has leaked or vented, it should be replaced immediately while avoiding to touch it without any protection.

Service and Inspection Precautions

1. Obey precautionary markings and instructions

Labels and stamps on the cabinet, chassis, and components identify areas requiring special precautions. Be sure to observe these precautions, as well as all precautions listed in the operating manual and other associated documents.

2. Use designated parts only

The set's components possess important safety characteristics, such as noncombustibility and the ability to tolerate large voltages. Be sure that replacement parts possess the same safety characteristics as the originals. Also remember that the \triangle mark, which appears in circuit diagrams and parts lists, denotes components that have particularly important safety functions; be extra sure to use only the designated components.

3. Always follow the original design when mounting parts and routing wires

The original layout includes various safety features, such as inclusion of insulating materials (tubes and tape) and the mounting of parts above the printer board. In addition, internal wiring has been routed and clamped so as to keep it away from hot or high-voltage parts. When mounting parts or routing wires, therefore, be sure to duplicate the original layout.

4. Inspect after completing service

After servicing, inspect to make sure that all

screws, components, and wiring have been returned to their original condition. Also check the area around the repair location to ensure that repair work has caused no damage, and confirm safety.

5. When replacing chip components...

Never reuse components. Also remember that the negative side of tantalum capacitors is easily damaged by heat.

6. When handling flexible print boards...


- The temperature of the soldering-iron tip should be about 270C.
- Do not apply the tip more than three times to the same pattern.
- Handle patterns with care; never apply force.

Caution: Remember that hard disk drives are easily damaged by vibration. Always handle with care.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFÉS PAR UNE MARQUE A SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈSES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPÉMENTS PUBLIÉS PAR SONY.

TABLE OF CONTENTS



Confidential

CHAPTER 1. SPECIFICATIONS

1-1. Specifications

		J								
	VGN-A61B	VGN-A51S2*/A51PS2*	VGN-A51S1*/A51PS1*	VGN-A71S*/A71PS*						
CPU	Pentium-M 1.6A(D)	*1)	*1)	*1)						
Graphic	Mobility Radeon 9700	Mobility Radeon 9200	Mobility Radeon 9200	Mobility Radeon 9700						
LCD	17.0"WXGA+ (Clear Black)	15.0"SXGA+ (Clear Black)	15.4"WXGA (Clear Black)	17.0"WUXGA (Clear Black)						
HDD	80GB	*2)	*2)	*2)						
MEMORY(Slot1)	512MB DDR333									
MEMORY(Slot2)	-	*3)	*3)	*3)						
QUANTITY[STANDARD/MAX]	512MB/2GB									
OPT-DRIVE	DVD Multi Drive	DVD Multi Drive	DVD Multi Drive	DVD Multi Drive						
		Combo	Combo	Combo						
AC adaptor	AC19V7	AC19V7/AC19V3	AC19V7/AC19V3	ombo Combo 7/AC19V3 AC19V7/AC19V3						
Battery	BP2EA	BP2EA	BP2EA	BP2EA						
Wireless LAN	0	0	0	0						
Bluetooth	X	х	X	Х						
AV PR	0	O/X	O/X	O/X						
Audio PR	X	х	X	X						
W-Mouse	0	х	0	0						
Memory Card Adapter	0	0	0	0						
Remote Controller	0	O/X	O/X	O/X						
os	XP Home	XP Home/XP Pro	XP Home/XP Pro	XP Home/XP Pro						
	∕ [MA]	∧ [MA]		<u>/</u> 2∖[MA]						

\(\triangle \begin{align*} \triangle \begin{a

[MA] *4]Mobile Cel 1.3,Mobile Cel 1.4(B),Pentium-M 1.54(D),Pentium-M 1.6(D),Pentium-M 1.8(D),Pentium-M 2.0(D) *5]100GB,80GB(5400pm),80GB,60GB,40GB *6]1024MB*1,1024MB*2,512MB*1,512MB*2,256MB*1,256MB*2

				AM			
	VGN-A290	VGN-A260	VGN-A250	VGN-A230*/A230B*/A230P*	VGN-A240*/A240B*/A240P*	VGN-A270*/A270B/A270P*	VGN-A290F
CPU	Pentium-M 1.7A(D)	Pentium-M 1.6A(D)	Pentium-M 1.6A(D)	*4)	*4)	*4)	Pentium-M 1.6A(D)
Graphic	Mobility Radeon 9700	Mobility Radeon 9200	Mobility Radeon 9200	Mobility Radeon 9200	Mobility Radeon 9200	Mobility Radeon 9700	Mobility Radeon 9200
LCD	17.0"WUXGA (Clear Black)	15.4"WXGA (Clear Black)	15.4"WXGA (Clear Black)	15.0"XGA/15.0"SXGA+ 15.4"WXGA (Clear Black) (Clear Black)		17.0"WUXGA/17.0"WXGA (Clear Black)	15.4"WXGA (Clear Black)
HDD	100GB	80GB	80GB	*5)	*5)	*5)	60GB
MEMORY(Slot1)	512MB DDR333	256MB DDR333	256MB DDR333				256MB DDR333
MEMORY(Slot2)	512MB DDR333	256MB DDR333	256MB DDR333	*6)	*6)	*6)	256MB DDR333
QUANTITYISTANDARD/MAXI	512MB/2GB	512MB/2GB	512MB/2GB				512MB/2GB
OPT-DRIVE	DVD+/-RW	DVD+/-RW	DVD+/-RW	DVD+/-RW Combo	DVD+/-RW Combo	DVD+/-RW Combo	DVD+/-RW
AC adaptor	AC19V7	AC19V7	AC19V3	AC19V7/AC19V3	AC19V7/AC19V3	AC19V7/AC19V3	AC19V3
Battery	BP2EA	BP2EA	BP2EA	BP2EA	BP2EA	BP2EA	BP2EA
Wireless LAN	0	0	0	O/X	O/X	0	0
Bluetooth	X	х	x	O/X	O/X	0	Х
AV PR	0	0	X	O/X	O/X	O/X	Х
Audio PR	X	х	x	х	х	x	Х
W-Mouse	X	х	X	Х	0	O/X	Х
Memory Card Adapter	X	х	х	Х	х	X	Х
Remote Controller	0	0	X	O/X	O/X	O/X	Х
os	XP Home	XP Home	XP Home	XP Pro/XP Pro SMB/ XP Home	XP Pro/XP Pro SMB/ XP Home	XP Pro/XP Pro SMB/ XP Home	XP Home
		<u></u> [MA]	<u></u> [MA]	<u></u> [MA]	<u></u> [MA]	<u></u> [MA]	<u></u> (MA)

• The trademarks or registered trademarks of above table, refer to page 2.

• The model that is accompanied by asterisk (*) is the CTO model For the equipment configuration, refer to the CTO Information.

・本表中の商標・登録商標については、2ページをご参照ください。

・機種名に (*) がつくのは CTO モデルです。 組み合わせについては、CTO Information ご確認ください。

			I	3 U			
	VGN-A297XP	VGN-A217S	VGN-A217M	VGN-A295HP	VGN-A215M	VGN-A215Z	
CPU	Pentium-M 1.8A(D)	Pentium-M 1.7A(D)	Pentium-M 1.6A(D)	Pentium-M 1.7A(D)	Pentium-M 1.6A(D)	Pentium-M 1.7A(D)	
Graphic	Mobility Radeon 9700	Mobility Radeon 9700	Mobility Radeon 9700	Mobility Radeon 9200	Mobility Radeon 9200	Mobility Radeon 9200	
LCD	17.0"WUXGA (Clear Black)	17.0"WXGA+ (Clear Black)	17.0"WXGA+ (Clear Black)	15.4"WXGA (Clear Black)	15.4"WXGA (Clear Black)	15.4"WXGA (Clear Black)	
HDD	80GB	100GB	80GB	60GB	60GB	60GB	
MEMORY(Slot1)	512MB DDR333	256MB DDR333	256MB DDR333	256MB DDR333	256MB DDR333	256MB DDR333	
MEMORY(Slot2)	-	-	-	-	-	256MB DDR333	
QUANTITY[STANDARD/MAX]	512MB/2GB	512MB/2GB	512MB/2GB	512MB/2GB	512MB/2GB	512MB/2GB	
OPT-DRIVE	DVD+/-RW	DVD+/-RW	DVD+/-RW	DVD+/-RW	DVD+/-RW	DVD+/-RW	
AC adaptor	AC19V3	AC19V7	AC19V3	AC19V3	AC19V3	AC19V3	
Battery	BP2EA	BP2EA	BP2EA	BP2EA	BP2EA	BP2EA	
Wireless LAN	0	0	0	0	0	0	
Bluetooth	0	0	0	0	х	0	
AV PR	X	0	X	х	X	Х	
Audio PR	Х	X	X	х	х	Х	
N-Mouse	0	0	0	х	X	х	
Memory Card Adapter	Х	X	Х	Х	х	Х	
Remote Controller	X	0	X	х	х	Х	
os	XP Pro	XP Home	XP Home	XP Pro	XP Home	XP Home	
·	<u></u> [MA]	<u> </u>	<u></u> [MA]	<u></u> [MA]	<u></u> [MA]	<u></u> [MA]	


			•	AO	•	•		
	VGN-A29CP	VGN-A23CP	VGN-A21C	VGN-A29GP	VGN-A29SP	VGN-A29LP	VGN-A29TP	
CPU	Pentium-M 2.0A(D)	Pentium-M 1.6A(D)	Pentium-M 1.5A(D)	Pentium-M 1.6A(D)	Pentium-M 1.6A(D)	Pentium-M 1.6A(D)	Pentium-M 1.6A(D)	
Graphic	Mobility Radeon 9700	Mobility Radeon 9200	Mobility Radeon 9200	Mobility Radeon 9200	Mobility Radeon 9200	Mobility Radeon 9200	Mobility Radeon 9200	
LCD	17.0"WUXGA (Clear Black)	15.0"XGA	15.4"WXGA (Clear Black)					
HDD	80GB	40GB	40GB	60GB	60GB	60GB	60GB	
MEMORY(Slot1)	512MB DDR333	256MB DDR333	256MB DDR333	512MB DDR333	512MB DDR333	512MB DDR333	512MB DDR333	
MEMORY(Slot2)	-	-	-	-	-	-	•	
QUANTITY[STANDARD/MAX]	512MB/2GB	512MB/2GB	512MB/2GB	512MB/2GB	512MB/2GB	512MB/2GB	512MB/2GB	
OPT-DRIVE	DVD+/-RW	Combo	Combo	DVD+/-RW	DVD+/-RW	DVD+/-RW	DVD+/-RW	
AC adaptor	AC19V7	AC19V3	AC19V3	AC19V3	AC19V3	AC19V3	DVD+/-RW AC19V3	
Battery	BP2EA	BP2EA	BP2EA	BP2EA	BP2EA	BP2EA	BP2EA	
Wireless LAN	0	0	0	0	0	0	0	
Bluetooth	X	Х	Х	Х	х	X	Х	
AV PR	X	х	х	х	Х	X	Х	
Audio PR	0	x	х	x	x	X	Х	
V-Mouse	X	х	х	х	Х	X	Х	
Memory Card Adapter	0	x	х	x	x	X	Х	
Remote Controller	0	х	x	х	х	X	Х	
os	XP Pro	XP Pro	XP Home	XP Pro	XP Pro	XP Pro	XP Pro	
	<u></u> (MA)	<u> </u>	<u></u> (MA)	<u></u> (MA)	<u></u> (MA)	<u></u> [MA]	<u> </u>	

- The trademarks or registered trademarks of above table, refer to page 2.
- The model that is accompanied by asterisk (*) is the CTO model For the equipment configuration, refer to the CTO Information.
- ・ 本表中の商標・登録商標については、2ページをご参照ください。
- ・機種名に (*) がつくのは CTO モデルです。 組み合わせについては、CTO Information ご確認ください。


1-2. CTO Information

Ver.1.0

1. Model name:VGN-A51PS2(Japanese Area) OS:Windows XP Pro




2. Model name:VGN-A51S2(Japanese Area) OS:Windows XP Home



3. Model name:VGN-A51PS1(Japanese Area) OS:Windows XP Pro

Ver.1.0




4. Model name:VGN-A51S1(Japanese Area) OS:Windows XP Home


Ver.1.0 Pentium-M 755 Pentium-M 745 Pentium-M 725 Celeron-M 330 CPU 6-706-559-01 6-600-306-01 6-600-355-01 6-706-572-01 IC RH80536GC0412MSL7EM IC RH80536GC0332MSL7EN IC RH80536GC0252MSL7EG IC RH80535NC017512SL6N6 HDD A-1083-188-A A-1062-140-A A-1065-502-A HDD (MHU2100AT-100GB) HDD (80GB,HTS548080M9AT00) ASSY HDD 60GB (-21) (I,40) (S) 15.4 WXGA LCD A-1072-741-A ASSY LCD(15.4WXGA)(H)(S) 1024MB*2 512MB*2 512MB*1 6-706-337-01x2 IC M470L6524BT0-CB3 6-706-244-01x2 Memory 6-706-337-01 IC EBD11UD8ADDA-6B IC M470L6524BT0-CB3 Super Multi/+DL Combo24 1-797-053-11 Opt.Drive 1-797-066-11 DVD+-RW(UJ-831BSX2-A) COMBO DRIVE(UJDA760) b/g(intel) 1-761-864-23 W-LAN WIRELESS LAN CARD Memory 1-478-615-11 Adapter MEMORY CARD ADAPTER TV Tuner PRAV1 None Replicator) WMS5 1-796-824-32 Mouse MOUSE (SLV)

Model name: VGN-A71PS(Japanese Area) OS:Windows XP Pro

Ver.1.0




Model name: VGN-A71S(Japanese Area) OS:Windows XP Home




<u></u> **△** [MA]

7. Model name:VGN-A230P(American Area) OS:Windows XP Pro Ver.1.0




Model name:VGN-A230(American Area)



9. Model name: VGN-A230B(American Area) OS: Windows XP Pro SMB Ver.1.0

Mouse




<u></u> **(MA)**


Confidential

VGN-A51PS1/A51PS2/A51S1/A51S2/A61B/A71PS/A71S VGN-A230/A230B/A230P/A240/A240B/A240P/A250/A260/A270/A270B/A270P/A290/A290F VGN-A215M/A215Z/A217M/A217S/A295HP/A297XP VGN-A21C/A23CP/A29CP/A29GP/A29LP/A29SP/A29TP


10. Model name: VGN-A240P(American Area) OS: Windows XP Pro Ver.1.0



11. Model name:VGN-A240(American Area) OS:Windows XP Home Ver.1.0



WMS5 1-796-824-32 MOUSE (SLV)




⚠[MA]


Confidential

VGN-A51PS1/A51PS2/A51S1/A51S2/A61B/A71PS/A71S VGN-A230/A230B/A230P/A240/A240B/A240P/A250/A260/A270/A270B/A270P/A290/A290F VGN-A215M/A215Z/A217M/A217S/A295HP/A297XP VGN-A21C/A23CP/A29CP/A29GP/A29LP/A29SP/A29TP


13. Model name:VGN-A270P(American Area) OS:Windows XP Pro Ver.1.0



14. Model name:VGN-A270(American Area) OS:Windows XP Home Ver.1.0



None




1-8 (END) **⚠[MA]**

Confidential


VGN-A51PS1/A51PS2/A51S1/A51S2/A61B/A71PS/A71S VGN-A230/A230B/A230P/A240/A240B/A240P/A250/A260/A270/A270B/A270P/A290/A290F VGN-A215M/A215Z/A217M/A217S/A295HP/A297XP VGN-A21C/A23CP/A29CP/A29GP/A29LP/A29SP/A29TP

CHAPTER 2. BLOCK DIAGRAM

2-1. VGN-A series




2-2. Port Replicator (VGP-PRAV)



CHAPTER 3. FRAME HARNESS DIAGRAM

3-1. VGN-A series SWX-166 BOARD (Side-B) HEADPHONE




ANTENNA ANTENNA

(Black)

LCD

LCD Block

3-2. Port Replicator (VGP-PRAV)



CHAPTER 4. EXPLODED VIEWS AND PARTS LIST

• The parts list is compiled by blocks of a palmrest and bottom etc. The sections of the parts list are different depending on the model. Please refer to list of contents shown in the below.

Section Page **Palmrest** Main Board M-1. Main Board (17-inch Model) 4-8 **Bottom** B-1. Bottom (17-inch Model) 4-14 **Optical Drive**

NOTE:

- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- · When two or more parts are shown, use the part described first as the main part.
- The parts marked "\$" are the High Value Modules (HVM).
- The parts marked "#" are the parts on which barcode label is attached.

For the barcode label, refer to CHAPTER 5.

- The parts marked " & " are the "Customer Replacable Parts (CRP)" that can be replaced by Field Customer Support. Especially the parts with the <&> mark require the special attention to use them. Here fore, check first whether the desired part is one of the targetted parts of the Customer Replaceable Parts(CRP), or the non-targetted parts by referring to the exploded view.
- Regarding the boards of this model, the discrete parts on the boards cannot be replaced. However, Some connectors can be replaced.
- The model that is accompanied by asterisk (*) is the CTO model.

For the equipment configuration, refer to the CTO Information.


The components identified by mark \triangle or dotted line with mark Replace only with part number specified.

Les composants identifiés par une marque A sont critiques pour la sécurité.

Ne les remplacer que par une pièce portant le numéro spécifié. ●分解図と部品表は、パームレスト、ボトムなどのブロックご とに分かれています。機種によって部品表のセクションが 異なりますので、詳細は右下の一覧表を参照してください。

Section Page

I CD




【使用上の注意】

- * 印の部品は常備在庫しておりません。
- ●図面番号のない部品は供給しません。
- ●併記部品の場合、上部記載部品をメイン部品として使用し てください。
- 部品名称の前に \$ 印のついた部品は、High Value Module (HVM)です。
- 商品名称の前に#印のついた部品は、バーコードラベル貼 付部品です。

バーコードラベルについてはCHAPTER5を参照してください。

- 部品名称の前に&印のついた部品は、お客様窓口などでも 交換可能な Customer Replacable Parts (CRP)です。 特に<&>印のついた部品は、使い分けが必要な部品ですの で, 分解図で Customer Replacable Parts 対象部品か, 対象 外部品かを必ず御確認ください。
- 本モデルの基板については、基板上の各部品の修理は行う ことができません。ただし、一部のコネクタについては、 修理可能です。
- 機種名に(*)がつくのはCTOモデルです。 組み合わせについては、CTO Informationを御確認ください。

△印の部品,または△印付きの点線で囲まれた部品 は、安全性を維持するために重要な部品です。従って 交換時は、必ず指定の部品を使用してください。




		Palmrest	Main Board	Bottom	Optical Drive	LCD	Accessories	Port Replicator		
	A51PS1*	P-3	M-3	B-3	D-1	L-5	A-1	A-2 (J-PR)		
	A51S1*	P-3	M-3	B-3	D-1	L-5	A-1	A-2 (J-PR)		
	A51PS2*	P-2	M-2	B-2	D-1	L-3	A-1	A-2 (J-PR)		A
J	A51S2*	P-2	M-2	B-2	D-1	L-3	A-1	A-2 (J-PR)	$\neg \neg$	— <u> </u>
	A61B	P-1	M-1	B-1	D-1	L-2	A-1	A-2 (J-PR)		
	A71PS*	P-1	M-1	B-1	D-1	L-1,L-2	A-1	A-2 (J-PR)		
	A71S*	P-1	M-1	B-1	D-1	L-1,L-2	A-1	A-2 (J-PR)	7—	
	A230*	P-2	M-2	B-2	D-1	L-3,L-4	A-1	A-2 (U-PR)	\neg	
	A230B*	P-2	M-2	B-2	D-1	L-3,L-4	A-1	A-2 (U-PR)	$\neg -$	
	A230P*	P-2	M-2	B-2	D-1	L-3,L-4	A-1	A-2 (U-PR)	$\neg -$	
	A240*	P-3	M-3	B-3	D-1	L-5	A-1	A-2 (U-PR)	7—	
	A240B*	P-3	M-3	B-3	D-1	L-5	A-1	A-2 (U-PR)	$\neg \rightarrow$	
А М	A240P*	P-3	M-3	B-3	D-1	L-5	A-1	A-2 (U-PR)	\neg	— <u>∧</u> [M/
	A250	P-3	M-3	B-3	D-1	L-5	A-1	<u> </u>	T	
	A260	P-3	M-3	B-3	D-1	L-5	A-1	A-2 (U-PR)	$\neg -$	
	A270*	P-1	M-1	B-1	D-1	L-1,L-2	A-1	A-2 (U-PR)	$\neg \neg$	
	A270B*	P-1	M-1	B-1	D-1	L-1,L-2	A-1	A-2 (U-PR)	$\neg -$	
	A270P*	P-1	M-1	B-1	D-1	L-1,L-2	A-1	A-2 (U-PR)	\neg	
	A290	P-1	M-1	B-1	D-1	L-1	A-1	A-2 (U-PR)		
	A290F	P-3	M-3	B-3	D-1	L-5	A-1	<u> </u>		<u></u> <u> </u>
	A215M	P-3	M-3	B-3	D-1	L-5	A-1		\neg	
	A215Z	P-3	M-3	B-3	D-1	L-5	A-1			— <u>∧</u> [M/
	A217M	P-1	M-1	B-1	D-1	L-2	A-1		7—	
ΕU	A217S	P-1	M-1	B-1	D-1	L-2	A-1	A-2 (E-PR)		— <u> </u>
	A295HP	P-3	M-3	B-3	D-1	L-5	A-1		\neg	
	A297XP	P-1	M-1	B-1	D-1	L-1	A-1		\neg	— <u></u>
	A29GP	P-3	M-3	B-3	D-1	L-5	A-1		7—1	213[
	A29SP	P-3	M-3	B-3	D-1	L-5	A-1		╗━	
	A29LP	P-3	M-3	B-3	D-1	L-5	A-1			∧[MA
٩O	A21C	P-3	M-3	B-3	D-1	L-5	A-1		٦—	
	A23CP	P-2	M-2	B-2	D-1	L-4	A-1		ק—וֹ	<u> </u>
	A29CP	P-1	M-1	B-1	D-1	L-1	A-1	A-2 (C-PR)	٦	
	A29TP	P-3	M-3	B-3	D-1	L-5	A-1	1	اـــــا	<u> </u>

VGN-A51PS1/A51PS2/A51S1/A51S2/A61B/A71PS/A71S VGN-A230/A230B/A230P/A240/A240B/A240P/A250/A260/A270/A270B/A270P/A290/A290F

> VGN-A215M/A215Z/A217M/A217S/A295HP/A297XP VGN-A21C/A23CP/A29CP/A29GP/A29LP/A29SP/A29TP

P-1. Palmrest (17-inch Model)




P-1. Palmrest (17-inch Model)

Ref.No.	Part No.	<u>Description</u>
1	A-1067-956-A	ASSY SPEAKER
2	A-1058-413-A	CABLE(20P), FLEXIBLE FLAT
3	A-1058-417-A	CABLE, KB LED
4	A-8068-824-A \$	COMPLETE PWB SWX-166
6	X-4626-655-2	SE1P PALMREST ASSY
7	4-682-423-01	SE1 SPONGE BT
8	2-159-644-01	SE1P SHEET SPEAKER RING
9	4-682-556-01	SE1P SPEAKER BRACKET
10	X-4626-657-1	SE1P TP BKT ASSY
11	4-682-560-01	TOUTCHPAD SHEET
12	2-103-688-01	SE1P TOUCHPAD GASKET
14	A-1058-427-A	PWB(12P),FLEXIBLE PRINT
15	A-1058-428-A	PWB(10P),FLEXIBLE PRINT
16	1-796-911-12	WIDE TOUCH PAD
17	2-103-691-01	SE1P BATT MASK MYLAR A
18	2-103-689-01	SE1P KEYBOARD BRACKET MYLAR A
19	2-103-690-01	SE1P KEYBOARD BRACKET MYLAR B
20	2-103-692-01	SE1P PALMREST GASKET
21	2-159-642-01	SE1P LED PORON
22	2-159-643-01	SE1P KEYBOARD SUPPORT MYLAR
23	2-159-977-01	SE1P KEYBOARD SUPPORT MYLAR B
24	2-548-305-01	SE1 MYLAR SPEAKER BKT
B2	4-672-836-21	SCREW, M2 SPECIAL HEAD,EG GRIP
B4	2-048-596-02	SCREW, +B EG GRIP
B5	4-672-836-11	SCREW, M2 SPECIAL HEAD,EG GRIP

				J				AM			EU		AO
			A61B	A71PS*	A71S*	A290	A270*	A270B*	A270P*	A297XP	A217S	A217M	A29CP
	Ref.Nc Part No.	Description										ıl	ı
[MA]	5 1-478-650-11	KEYBÖARD UNIT (JP)	•	•	•								
	1-478-650-21	KEYBOARD UNIT (US)				•	•	•	•				•
[MA]	1-478-640-11	KEYBOARD UNIT (GB)								•	•	•	
[MA] [MA] [MA]	1-478-640-21	KEYBOARD UNIT (DE)								•	•	•	
[MA]	1-478-640-31	KEYBOARD UNIT (CH)								•	•	•	
[MA]	1-478-640-41	KEYBOARD UNIT (FR)								•	•	•	
[MA]	1-478-640-51	KEYBOARD UNIT (IT)								•	•	•	-1
[MA]	1-478-640-61	KEYBOARD UNIT (ES)								•	•	•	-1
[MA]	1-478-640-71	KEYBOARD UNIT (SE)								•			
[MA]	1-478-640-81	KEYBOARD UNIT (PT)								•		\Box	
				◬	◬		A	A	\triangle	A	Δ	Δ	4

- This parts list contains two different types of parts.
 The first type is the parts that are common to all models.
 The other type is the parts that are different depending on each model.
- This model that is accompanied by asterisk (*) is the CTO model.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- 機種名に(*)がつくのは CTO モデルです。

P-2. Palmrest (15-inch Model)



P-2. Palmrest (15-inch Model)

Ref.No.	Part No.	Description
1	A-1067-956-A	ASSY SPEAKER
2	A-1058-413-A	CABLE(20P), FLEXIBLE FLAT
3	A-1058-417-A	CABLE, KB LED
4	A-8068-824-A \$	COMPLETE PWB SWX-166
7	4-682-423-01	SE1 SPONGE BT
24	2-548-305-01	SE1 MYLAR SPEAKER BKT
101	X-4626-648-1	SE1 15S PALM SUB ASSY
102	4-682-425-01	SE1 BRACKET SPEAKER L
103	4-682-424-01	SE1 BRACKET SPEAKER R
104	X-4626-724-1	SE1 TOUCHPAD BRACKET ASSY
105	A-1058-423-A	PWB(12P),FLEXIBLE PRINT
106	1-796-319-72	PAD, TOUCH
107	2-103-455-01	SE1 TOUCHPAD FPC PORON
108	2-103-022-01	SE1 KEYBOARD BRACKET GASKET
109	2-159-976-01	SE1 MAYLAR KEYBOARD
110	2-159-786-01	SE1 MYLAR TOUCH-PAD FPC
111	4-682-941-01	SE1 RING GLUE
112	2-103-453-01	SE1 MYLAR KEYBOARD BRACKET U
113	2-103-454-01	SE1 MYLAR KEYBOARD BRACKET L
114	2-176-528-01	SE1 TOUCHPAD TAPE
B1	4-672-836-01	SCREW,M2 SPECIAL HEAD EG GRIP
B4	2-048-596-02	SCREW, +B EG GRIP
B5	4-672-836-11	SCREW, M2 SPECIAL HEAD, EG GRIP
B7	4-644-637-21	GRIP, M2 EG


					J		AM		AO
		D.(N. D.(N.	Provide	A51PS2*	A51S2*	A230*	A230B*	A230P*	A23CP
Δ	[MA]	Ref.No. Part No.	Description (FXPOARD LINE (ID)	_	-			_	-
◬	[[V]	5 1-478-650-11	KEYBOARD UNIT (JP)	•	•				
		1-478-650-21	KEYBOARD UNIT (US)		1	•	•	•	•
				△	◬				<u> </u>
		This parts list contains two different types of parts.		MA]	MA]				MA]

- The first type is the parts that are common to all models.

 The other type is the parts that are different depending on each model.
- This model that is accompanied by asterisk (*) is the CTO model.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- ●機種名に(*)がつくのは CTO モデルです。

△[MA]

Confidential




P-3. Palmrest (15.4-inch Model)

Ref.No.	Part No.	Description
1 2	A-1067-956-A A-1058-413-A	SE/SE+ SPEAKER SET CABLE(20P), FLEXIBLE FLAT
3	A-1058-417-A	CABLE, KB LED
4	A-8068-824-A \$	COMPLETE PWB SWX-166
7	4-682-423-01	SE1 SPONGE BT
8	2-159-644-01	SE1P SHEET SPEAKER RING
9	4-682-556-01	SE1P SPEAKER BRACKET
18	2-103-689-01	SE1P KEYBOARD BRACKET MYLAR A
19	2-103-690-01	SE1P KEYBOARD BRACKET MYLAR B
24	2-548-305-01	SE1 MYLAR SPEAKER BKT
106	1-796-319-72	PAD,TOUCH
109	2-159-976-01	SE1 MYLAR KEYBOARD
201	X-2021-746-1	SEM PALM SUB ASSY
202	X-2021-752-1	SEM TOUCHPAD BRACKET ASSY
203	4-676-956-01	GASKET T/P CONTACT
204	A-1067-142-A	TP(M),FLEXIBLE PRINT
205	2-050-875-01	SEM T/P HOOK
550	2-159-787-01	SE1 SPONGE LENS
B1	4-672-836-01	SCREW, M2 SPECIAL HEAD,EG GRIP
B5	4-672-836-11	SCREW, M2 SPECIAL HEAD,EG GRIP
B7	4-644-637-21	GRIP M2 EG

				J			ΑŅ	И				EU				АО		
			A51PS1*	A51S1*	A260	A250	A240*	A240B*	AZ40F	AZSOF	AZSOHP	AZISM	A2152	A29GP	A29SP	A29LP	A29TP	A21C
L	Ref.No. Part No.	Description										\perp						
[MA]	5 1-478-650-11	KEYBÔARD UNIT (JP)	•	•													\perp	
L	1-478-650-21	KEYBOARD UNIT (US)			•	•	•	•	•					•			\perp	•
[MA]	1-478-650-31	KEYBOARD UNIT (LA)								•							\perp	
[MA]	1-478-650-41	KEYBOARD UNIT (KR)														•		
	1-478-650-51	KEYBOARD UNIT (TH)													•			
[MA]	1-478-650-61	KEYBOARD UNIT (TW)															•	
	1-478-640-11	KEYBOARD UNIT (GB)									•	•	•					
	1-478-640-21	KEYBOARD UNIT (DE)									•	•	•					
	1-478-640-31	KEYBOARD UNIT (CH)									•	•						
	1-478-640-41	KEYBOARD UNIT (FR)									•	•						
	1-478-640-51	KEYBOARD UNIT (IT)									•	•	•					
	1-478-640-61	KEYBOARD UNIT (ES)									•	•						
	1-478-640-71	KEYBOARD UNIT (SE)									•							
	1-478-640-81	KEYBOARD UNIT (PT)									•							
	This parts list contains two different types The first type is the parts that are common		[MA]	[MA] ₪							·	·				[MA] №	[MA]	[MA]

- This parts list contains two different types of parts.
 The first type is the parts that are common to all models.
 The other type is the parts that are different depending on each model.
- This model that is accompanied by asterisk (*) is the CTO model.
- ●この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- 機種名に(*)がつくのは CTO モデルです。




M-1. Main Board (17-inch Model)

Ref.No.	Part No.	Description
301 304 305 306 307	A-1058-426-A A-1083-174-A \$ # 4-682-945-01 X-2022-962-2 4-682-478-01	CABLE, RJ11 COMPLETE PWB MBX-110 SE+ SE1 2ND FAN MYLAR SE1 DC JACK HOLDER ASSY SE1 ODD INSULATOR
308	4-682-942-01	SE1 PCMCIA MYLAR
309	4-682-475-01	SE1 SHEET MINI-PCI
310	4-682-569-01	SE1P CARD BOX BRACKET
311	X-4626-661-1	SE1P IO BRACKET ASSY
312	1-756-038-11	BATTERY,NICKEL HYDROGEN
313	4-642-711-11	SHEET (BATTERY), ADHESIVE
314	4-668-307-01	SHEET DIMM
315	A-1058-414-A	HARNESS,DC
316	A-1067-298-A	CONNECTOR(SE+),PC CARD
317	A-8119-893-A	SE1 FIN THERMAL MODULE
318 319 321 322 323	A-8119-892-A \$ 2-103-694-01 1-761-606-14 # 4-682-465-01 2-103-444-01	SE1 THERMAL MODULE SE1P VGA THERMAL PAD CARD,MODEM SE1 MYLAR DOOR DIMM SE1 EMI SPRING FIN
324	X-2022-963-1	SE1 EMI SPRING BATT-1 ASSY
326	4-683-063-01	RJ11 BKT
327	2-176-527-01	2ND FAN MYLAR-1
328	2-103-452-01	CPU THERMAL PAD
329	2-103-693-01	SE1P THERMAL MODULE GASKET
330	A-8068-828-A	COMPLETE PWB CNX-256
B1	4-672-836-01	SCREW, M2 SPECIAL HEAD,EG GRIP
B3	4-672-834-41	SCREW, +B EG GRIP
B4	2-048-596-02	SCREW, +B EG GRIP
B5	4-672-836-11	SCREW, M2 SPECIAL HEAD,EG GRIP
B6	4-656-703-01	SCREW, M2
B13	2-103-443-01	SE1 HEX2-5+7
B14	4-635-966-01	SCREW(HEX)

	Γ										J			ΑN	1			EU		AO
		Ref No	. Part No.			De	escription			A61B	A71PS*	A71S*	A290	A270*	A270B*	A270P*	A297XP	A217S	A217M	A29CP
Λ	[MA]	302	6-706-559-01				RH80536GC	C0412MSL7E	M(P-M2.0)	•	•	•	\vdash	•	•	•				•
*	ΪΜΑΊ		6-600-306-01				RH80536GC				•	•	-	•	•	•	•			_
	' '		6-600-343-01				RH80536G0					П	•	•	•	•		•		
Λ	[MA]		6-600-355-01			IC	RH80536G0	C0252MSL7E	EG(P-M1.6)		•	•		•	•	•			•	_
Λ	įΜΑį		6-600-368-01				RH80536GC					П		•	•	•				
Λ	[MA]		6-706-572-01			IC	RH80535NC	C017512SL6	N6(Cel-M1.4)		•	•		•	•	•				_
	[MA]		6-707-262-01			IC	RH80536NC	0131M (Cel-	-M1.3)					•	•	•				
$\overline{\Lambda}$	[MA]	303	6-706-244-01			IC	EBD11UD8A	ADDA-6B(1G	iB)		•	•		•	•	•				
	1		6-706-337-01			IC	M470L6524	BT0-CB3(51	2MB)	•	•	•	•	•	•	•	•			•
Λ	[MA]		6-707-051-01			IC	MT8VDDT32	264HDY-335	F4 (256MB)			\Box		•	•	•		•	•	
		320	1-761-864-14	#		WI	RELESS LA	N CARD				П	•	•	•	•				
	[MA]		1-761-864-23	#			RELESS LA			•										
Δ	[MA]		1-761-864-33	#			RELESS LA										•	•	•	•
\triangle	[MA]		1-761-891-12	#		WI	RELESS LAI	N CARD			•	•								
_ _			P switch setting, re								_ [MA] <mark></mark>	[MA]		[MA]	_	[MA]	[MA] [≽	[MA]	_	[MA]

- 1) The DIP switch setting, refer to page 4-35 "DIP switch".
- 2) The CPU THERMAL PAD (Ref.328) cannot be re-used if it is removed once. When the FIN THERMAL MODULE (Ref.317) is removed, be sure to replace it with the new one.
- 3) When change the CPU (Ref.302), refer to "5-2 Replacing the CPU "in CHAPTER 5.
- 1) DIP スイッチの設定は、4-35頁「DIP Switch」を参照してください。
- 2) CPU THERMAL PAD (Ref.328) は、一度取り外したものを再利用することはできません。 FIN THERMAL MODULE (Ref.317) をはずした場合には、必ず新しいものを交換してください。
- 3) CPU (Ref.302) を交換する際は、CHAPTER 5、「5-2 CPU の交換」を参照してください。
- · This parts list contains two different types of parts. The first type is the parts that are common to all models. The other type is the parts that are different depending on each model.
- This model that is accompanied by asterisk (*) is the CTO model.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- ●機種名に(*)がつくのは CTO モデルです。



VGN-A51PS1/A51PS2/A51S1/A51S2/A61B/A71PS/A71S VGN-A230/A230B/A230P/A240P/A240B/A240P/A250/A250/A250B/A270P/A250/A250S VGN-A215M/A2152/A217M/A217S/A225HP/A297XP VGN-A21C/A23CP/A29CP/A29GP/A29LP/A29SP/A29TP

[MA] 🕏

M-2. Main Board (15-inch Model)

Ref.No.	Part No.	<u>Description</u>
108	2-103-022-01	KEYBOARD BRACKET GASKET
305	4-682-945-01	SE1 2ND FAN MYLAR
306	X-2022-962-2	SE1 DC JACK HOLDER ASSY
307	4-682-478-01	SE1 ODD INSULATOR
308	4-682-942-01	SE1 PCMCIA MYLAR
309	4-682-475-01	SE1 SHEET MINI-PCI
312	1-756-038-11	BATTERY,NICKEL HYDROGEN
313	4-642-711-11	SHEET (BATTERY), ADHESIVE
314	4-668-307-01	SHEET DIMM
315	A-1058-414-A	HARNESS,DC
317	A-8119-893-A	SE1 FIN THERMAL MODULE
318	A-8119-892-A	SE1 THERMAL MODULE
321	1-761-606-14	MODEM CARD
322	4-682-465-01	SE1 MYLAR DOOR DIMM
323	2-103-444-01	EMI SPRING FIN
324	X-2022-963-1	EMI SPRING BATT-1 ASSY
327	2-176-527-01	2ND FAN MYLAR-1
328	2-103-452-01	CPU THERMAL PAD
401	A-1058-422-A	CABLE, RJ11
402	A-1083-176-A \$ #	COMPLETE PWB MBX-110 SE2
403 404 405 406 407	X-4626-725-1 4-682-943-01 4-676-423-01 4-682-442-01 A-1067-297-A	SE1 BRACKET I/O ASSY SE1 CARDBUS CONN SPONGE VGA THERMAL PAD SE1 RJ11 BRACKET CONNECTOR(SE),PC CARD
408	2-103-446-01	SE1 GASKET RJ11
409	2-103-445-01	SE1 GASKET CARD BOX
410	A-8068-826-A	COMPLETE PWB CNX-246
411	4-682-950-01	SE1 ODD BOARD MYLAR
B1	4-672-836-01	SCREW, M2 SPECIAL HEAD,EG GRIP
B3	4-672-834-41	SCREW, +B EG GRIP
B4	2-048-596-02	SCREW, +B EG GRIP
B5	4-672-836-11	SCREW, M2 SPECIAL HEAD,EG GRIP
B6	4-656-703-01	SCREW, M2
B7	4-644-637-21	GRIP, M2 EG
B13	2-103-443-01	SE1 HEX2-5+7
B14	4-635-966-01	SCREW (HEX)

				J			AM		AO
				A51PS2*	A51S2*	A230*	A230B*	A230P*	A23CP
	Ref.No.	Part No.	Description						
	302	6-706-559-01	IC RH80536GC0412MSL7EM(P-M2.0)	•	•	•	•	•	
Г		6-600-306-01	IC RH80536GC0332MSL7EN(P-M1.8)	•	•	•	•	•	
		6-600-343-01	IC RH80536GC0292MSL7EP(P-M1.7)			•	•	•	
		6-600-355-01	IC RH80536GC0252MSL7EG(P-M1.6)	•	•	•	•	•	•
		6-600-368-01	IC RH80536GC0212MSL7GL(P-M 1.5)			•	•	•	
Г		6-706-572-01	IC RH80535NC017512SL6N6(Cel-M1.4)	•	•	•	•	•	
Г		6-707-262-01	IC RH80536NC0131M (Cel-M1.3)			•	•	•	
Г	303	6-706-244-01	IC EBD11UD8ADDA-6B(1GB)	•	•	•	•	•	
Г		6-706-337-01	IC M470L6524BT0-CB3(512MB)	•	•	•	•	•	
Г		6-707-051-01	IC MT8VDDT3264HDY-335F4 (256MB)			•	•	•	•
	320	1-761-864-14	# WIRELESS LAN CARD	T		•	•	•	
1A] [1-761-864-23	# WIRELESS LAN CARD	•	•				
1A][1-761-864-33	# WIRELESS LAN CARD						•




1) The DIP switch setting, refer to page 4-35 "DIP switch".

The CPU THERMAL PAD (Ref.328) cannot be re-used if it is removed once.
 When the FIN THERMAL MODULE (Ref.317) is removed, be sure to replace it with the new one.

3) When change the CPU (Ref.302), refer to "5-2 Replacing the CPU "in CHAPTER 5.

- 1) DIP スイッチの設定は、4-35頁「DIP Switch」を参照してください。
- 2) CPU THERMAL PAD (Ref.328) は、一度取り外したものを再利用することはできません。 FIN THERMAL MODULE (Ref.317) をはずした場合には、必ず新しいものを交換してください。
- 3) CPU (Ref.302) を交換する際は、CHAPTER 5、「5-2 CPU の交換」を参照してください。
- This parts list contains two different types of parts.
 The first type is the parts that are common to all models.
 The other type is the parts that are different depending on each model.
- This model that is accompanied by asterisk (*) is the CTO model.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- 機種名に(*)がつくのは CTO モデルです。



M-3. Main Board (15.4-inch Model)

Ref.No.	Part No.	Description
301 305 306 307 308	A-1058-426-A 4-682-945-01 X-2022-962-2 4-682-478-01 4-682-942-01	CABLE, RJ11 SE1 2ND FAN MYLAR SE1 DC JACK HOLDER ASSY SE1 ODD INSULATOR SE1 PCMCIA MYLAR
309	4-682-475-01	SE1 SHEET MINI-PCI
312	1-756-038-11	BATTERY, NICKEL HYDROGEN
313	4-642-711-11	SHEET (BATTERY), ADHESIVE
314	4-668-307-01	SHEET DIMM
315	A-1058-414-A	HARNESS, DC
317	A-8119-893-A	SE1 FIN THERMAL MODULE
318	A-8119-892-A \$	SE1 THERMAL MODULE
321	1-761-606-14 #	CARD,MODEM
322	4-682-465-01	SE1 MYLAR DOOR DIMM
323	2-103-444-01	SE1 EMI SPRING FIN
326	4-683-063-01	RJ11 BKT
327	2-176-527-01	SE1 2ND FAN MYLAR-1
328	2-103-452-01	CPU THERMAL PAD
329	2-103-693-01	SE1P THERMAL MODULE GASKET
404	4-682-943-01	CARDBUS CONN ,SPONGE
405	4-676-423-01	VGA THERMAL PAD
409	2-103-445-01	SE1 GASKET CARD BOX
451	A-1083-175-A \$ #	COMPLETE PWB MBX-110 SE2M
452	2-050-884-01	SEM BRACKET CARD BOX
453	X-2021-754-1	SEM BRACKET I/O ASSY
454	A-1067-143-A	PC-CARD(M),FLEXIBLE PRINT
455	X-2023-152-1	SEM EMI SPRING BATT-1 ASSY
456	A-1067-139-A	COMPLETE PWB CNX-267
B1	4-672-836-01	SCREW, M2 SPECIAL HEAD,EG GRIP
B3	4-672-834-41	SCREW, +B EG GRIP
B4	2-048-596-02	SCREW, +B EG GRIP
B5	4-672-836-11	SCREW, M2 SPECIAL HEAD,EG GRIP
B6	4-656-703-01	SCREW, M2
B13	2-103-443-01	SE1 HEX2-5+7

SCREW(HEX)

4-635-966-01


◬ 4

						J			Α	М								АО		_
					A51PS1*	A51S1*	A260	A250	A240*	A240B*	A240P*	A290F	A295HP	A215M	A215Z	A29GP	A29SP	A29LP	A29TP	A21C
		c Part No.		Description																
	302	6-706-559-01		IC RH80536GC0412MSL7EM(P-M2.0)	•	_			•	•	•									
		6-600-306-01		IC RH80536GC0332MSL7EN(P-M1.8)	•	•			•	•	•									
		6-600-343-01		IC RH80536GC0292MSL7EP(P-M1.7)					•	•	•		•		•					
		6-600-355-01		IC RH80536GC0252MSL7EG(P-M1.6)	•	•	•	•	•	•	•	•		•		•	•	•	•	
		6-600-368-01		IC RH80536GC0212MSL7GL(P-M 1.5)					•	•	•									•
		6-706-572-01		IC RH80535NC017512SL6N6(Cel-M1.4)	•	•			•	•	•									
		6-707-262-01		IC RH80536NC0131M (Cel-M1.3)					•	•	•									
	303	6-706-244-01		IC EBD11UD8ADDA-6B(1GB)	•	•			•	•	•									
		6-706-337-01		IC M470L6524BT0-CB3(512MB)	•	•			•	•	•		•			•	•	•	•	
		6-707-051-01		IC MT8VDDT3264HDY-335F4 (256MB)		1	•	•	•	•	•	•		•	•					•
	320	1-761-864-14	#	WIRELESS LAN CARD			•	•	•	•	•	•								_
[MA]		1-761-864-23	#	WIRELESS LAN CARD	•	•														_
` 1		1-761-864-33	#	WIRELESS LAN CARD									•	•	•	•	•	•		•
[MA]		1-761-864-15	#	WIRELESS LAN CARD															•	_
							-						_					_		_
						Δ						◬						4	_	Ճ
					[MA]	[MA]						[MA]						7	[MA]	[MA]
		switch setting, refer			Ì	Š						ŝ						[MA]	\geq	⋛

- 1) The DIP switch setting, refer to page 4-35 "DIP switch".
- 2) The CPU THERMAL PAD (Ref.328) cannot be re-used if it is removed once. When the FIN THERMAL MODULE (Ref.317) is removed, be sure to replace it with the new one.
- 3) When change the CPU (Ref.302), refer to "5-2 Replacing the CPU "in CHAPTER 5.
- 1) DIP スイッチの設定は、4-35 頁「DIP Switch」を参照してください。
- 2) CPU THERMAL PAD (Ref.328) は、一度取り外したものを再利用することはできません。 FIN THERMAL MODULE (Ref.317) をはずした場合には、必ず新しいものを交換してください。
- 3) CPU (Ref.302) を交換する際は、CHAPTER 5、「5-2 CPU の交換」を参照してください。
- · This parts list contains two different types of parts. The first type is the parts that are common to all models. The other type is the parts that are different depending on each model.
- This model that is accompanied by asterisk (*) is the CTO model.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- ●機種名に(*)がつくのは CTO モデルです。

⚠[MA]


B-1. Bottom (17-inch Model)



B-1. Bottom (17-inch Model)

Ref.No.	Part No.		Description
7	4-682-423-01		SE1 SPONGE BT
501	A-1058-406-A		CABLE(26P), FLEXIBLE FLAT
502	A-1058-416-A		CABLE, ODD EJECT
504 505	A-8068-827-A \$ A-8068-830-A \$ #		COMPLETE PWB CNX-247 COMPLETE PWB IFX-335
506	X-4626-658-2		SE1P BOTTOM ASSEY
507	4-682-454-01		SE1 15S BATT BUTTON
508 509	4-682-455-01 4-682-460-01		SE1 15S BATT BUTTON3 SE1 15S DOOR DOCK
510	4-682-457-01		SE1 BATT LOCK
511	4-683-040-01		SE1 DOCKING HOOK MYLAR
512	4-682-443-01	&	SE1 FOOT FRONT
513	4-682-444-01	&	
514	4-682-445-01		SE1 FOOT REAR
515 516	4-682-456-01 4-682-459-01		SE1 LATCH BATT SE1 LATCH BATT SPRING
310	4-002-439-01		SET EATON DATT SETTING
517	4-682-479-01		SE1 EMI SPRING BATT
518 519	4-682-458-02 4-682-476-01		SE1 LATCH LEVER SE1 SW BRACKET
520	2-103-697-01		SE1P HDD MYLAR
521	2-103-698-01		SE1P INSULATION AUDIO BD
522 523	4-682-447-01 X-4626-721-1	&	SE1 LCD LATCH DETECTOR SE1 DOOR I/O ASSY
523	X-4626-653-1	α &	
525	X-4626-720-1	&	SE1 BATTERY DOOR ASSY
526	2-025-132-01	&	LABEL BATTERY
527	4-682-466-01	&	SE1 15S DOOR MODEM
535	4-682-580-01		SE1P BRACKET HDD-L
536	4-682-581-01		SE1P BRACKET HDD-R
538 541	4-682-568-01 2-103-696-01		SE1P DISPLAY BASE SE1P SHEET BLUETOOTH ANT
541	2-103-696-01		SEIP SHEET BLUETOOTH AINT
542	2-103-695-01		SE1P BATT MASK MYLAR B
543 544	A-8068-825-A \$ A-1058-429-A		COMPLETE PWB CNX-245 PWB(20P),FLEXIBLE PRINT
545	4-682-462-01		SE1 15S MODEM R
547	2-067-843-01		EMI SPRING HDD
550	2-159-787-01		SE1 SPONGE LENS
B1	4-672-836-01		SCREW, M2 SPECIAL HEAD,EG GRIP
B2	4-672-836-21		SCREW, M2 SPECIAL HEAD,EG GRIP
B3	4-672-834-41		SCREW, +B EG GRIP
B4 B5	2-048-596-01 4-672-836-11		> SCREW, +B EG GRIP > SCREW, M2 SPECIAL HEAD,EG GRIP
DO	4-0/2-030-11	<α2	SOLLW, WE SECURE READ, EG GRIP
B9	2-159-307-01	<&>	SCREW, M2.6+B EG GRIP
B11	4-672-839-01		HEAD,M3 FLAT
B12 B18	4-672-840-01 4-672-834-21	-8.	SCREW, M2 TAPPING,FLAT HEAD SCREW, +B EG GRIP
B23	3-254-029-11	-α.	SCREW
B24	4-672-834-71	<&>	SCREW,+B EG GRIP


	Γ									J			Αľ	М		<u> </u>	ВU		AO
		5.01	B						A61B	A71PS*	A71S*	A290	A270*	A270B*	A270P*	A297XP	A217S	A217M	A29CP
^	18.461		. Part No.				Description Description	01105		-	•	├	Ļ	Ļ	•		_	_	_
4	[MA]	503 528	A-1058-408-A 4-682-449-01				CABLE, WIRELESS MO		•	•	•	_	•	•	•	•	•	•	_
Δ	[MA]	526					SE1 LENS PANEL CT		-	-	•		_	_	_	_	_	<u> </u>	_
^	[MA]	529	4-682-449-11 4-683-065-01				SE1 LENS PANEL CTO SE1P BUTTON COVER	D DE(M/M/MANA)	- 1:	•	÷	•		•	•	•	•	•	•
213	[ivi~j]	530	4-683-066-01				SE1P PANEL RF CTO			•	•	•	•		-	-	<u> </u>	<u> </u>	•
^	[MA]	531	4-682-582-01				SE1P BUTTON RF(W/		-	•	•	-		-	-		•	•	•
2	[MA]	532	4-682-583-01				SE1P SPRING RF KN		- -	-	-	├			-		-	-	-
	[MA]	533	1-796-949-11				USB RF MOUSE RECI				÷	_	•		•		•	•	-
\}	[MA]	534	A-8067-943-A	\$	#		ASSY HDD 80GB (I,40			•	÷		•	•	•	•	<u> </u>	•	-
\}	[MA]	334	A-1062-140-A	φ φ	#		HDD (80GB,HTS5480			÷	÷	\vdash		•	•	-	\rightarrow	<u> </u>	—
***	[MA]		A-1083-189-A	φ φ	#		HDD (MHT2080AT-800		-	÷	÷	\vdash	-	Ľ	_	\vdash	\rightarrow	\rightarrow	•
<u>/2</u>	[MA]		A-1065-502-A	φ φ	#		ASSY HDD 60GB(-21)			÷	-		•	•	•	\vdash	\rightarrow	\dashv	_
213	1,4,4,4		A-1083-188-A	Φ Φ	#		HDD (MHU2100AT-100			•	÷	•	•	•	•	\vdash	•	\rightarrow	—
A	[MA]		A-1083-186-A	<u>Ψ</u>	#		HDD(40GB,HTS42404			Ť	Ť	Ť	•	•	•	\vdash	\dashv	\dashv	-
*	[MA]	539	1-805-554-11	Ψ	π		BLUETOOTH MODULE						•		•		•	•	-
*	IMA]	540	A-1058-407-A				CABLE, BT ANTENNA	_				 	•		•	i	•	•	\dashv
213	[,,,,,]	548	4-682-446-01				SE1 SWICH W LAN(W.	/WL)	•	•	•	•	•		•		•	•	•
		3.0						,		_	<u> </u>	<u> </u>		_	_	$\overline{}$	$\overline{}$	_	~
									◬	◬	4		△	₾	盔	△	△	△	[MA]
									Ζ	4	4		Ø	Ø	Ø	⋖	⋖	⋖	4
									[MA]	[MA]	[MA]		[MA]	[MA]	[MA]	[MA]	[MA]	[MA]	≥





- 2) Ref.503, 532, 533 は、Wireless-Mouse 付モデル用の部品です。

- This parts list contains two different types of parts.
 The first type is the parts that are common to all models.
 The other type is the parts that are different depending on each model.
- This model that is accompanied by asterisk (*) is the CTO model.
- ●この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- 機種名に(*) がつくのは CTO モデルです。



B-2. Bottom (15-inch Model)

Ref.No.	Part No.			Description
501	A-1058-406-A			CABLE(26P), FLEXIBLE FLAT
502	A-1058-416-A			CABLE, ODD EJECT
504	A-8068-827-A	\$		COMPLETE PWB CNX-247
507	4-682-454-01			SE1 15S BATT BUTTON
508	4-682-455-01			SE1 15S BATT BUTTON3
509	4-682-460-01			SE1 15S DOOR DOCK
510	4-682-457-01			SE1 BATT LOCK
511	4-683-040-01			SE1 DOCKING HOOK MYLAR
512	4-682-443-01		&	SE1 FOOT FRONT
513	4-682-444-01		&	SE1 FOOT FRONT CENTER
F4.4	4 000 445 04			054 5007 0540
514	4-682-445-01			SE1 FOOT REAR
515	4-682-456-01			SE1 LATCH BATT
516	4-682-459-01			SE1 LATCH BATT SPRING
517	4-682-479-01			SE1 EMI SPRING BATT
518	4-682-458-02			SE1 LATCH LEVER
519	4-682-476-01			SE1 SW BRACKET
522	4-682-447-01			LCD LATCH DETECTOR
523	X-4626-721-1		&	SE1 DOOR I/O ASSY
524	X-4626-653-1		&	
525	X-4626-720-1		&	SE1 BATTERY DOOR ASSY
020	X 1020 720 1		~	02. 2/11/2111 20011/1001
526	2-025-132-01		&	LABEL BATTERY
527	4-682-466-01		&	SE1 15S DOOR MODEM
543	A-8068-825-A			COMPLETE PWB CNX-245
545	4-682-462-01			MODEM R
546	2-103-447-01			THERMAL MODULE GASKET
547	2-067-843-01			EMI SPRING HDD
550	2-159-787-01			SE1 SPONGE LENS
601	2-024-791-01			SE1 HDD MYLAR
602	4-682-477-01			SE1 DISPLAY BASE
603	X-4626-650-2			SE1 BOTTOM CASE MODULE
604	A-8068-829-A	\$ #		COMPLETE PWB IFX-324
605	4-682-418-01	Ψ″		SE1 BRACKET HDD
607	A-1058-424-A			PWB(20P), FLEXIBLE PRINT
608	2-159-785-01			SE1 BATTERY CONN MYLAR-1
609	4-672-493-01			COVER(SC)
B1	4-672-836-01		<&>	SCREW, M2 SPECIAL HEAD, EG GRIP
B3	4-672-834-41		<&>	SCREW, M2 SPECIAL HEAD
B4	2-048-596-02		<&>	SCREW, +B EG GRIP
B5	4-672-836-11		<&>	SCREW, M2 SPECIAL HEAD
B7	4-644-637-21		<&>	GRIP, M2 EG
	0.450.007.51		•	
B9	2-159-307-01		<&>	SCREW, M2.6+B EG GRIP
B11	4-672-839-01		.0	HEAD,M3 FLAT
B18	4-672-834-21		<&>	SCREW, +B EG GRIP
B23	3-254-029-11		•	SCREW DECORPO
B24	4-672-834-71		<&>	SCREW,+B EG GRIP


				LJ			AM		ΑO
				A51PS2*	A51S2*	A230*	A230B*	A230P*	A23CP
Ref.No.	. Part No.		Description						
528	4-682-449-11		SE1 LENS PANEL CTO(W/WL,No-BT)	•	•	•	•	•	•
	4-682-449-21		SE1 LENS PANEL CTO(No-WL,No-BT)			•	•	•	
534	A-1062-140-A	\$ #	HDD_(80GB,HTS548080M9AT00)_(S)	•	•	•	•	•	
	A-8067-943-A	\$ #	ASSY HDD 80GB (I,40) (S)			•	•	•	
	A-1065-502-A	\$ #	ASSY HDD 60GB(-21)(I,40)(S)	•	•	•	•	•	
	A-1083-188-A	\$ #	HDD (MHU2100AT-100GB) (S)	•	•	•	•	•	
	A-1083-186-A	\$ #	HDD(40GB,HTS424040)(S)			•	•	•	•
548	4-682-446-01		SE1 ŚWICH W LAN(W/ŴL)	•	•	•	•	•	•
549	4-682-448-01		SE1 ESCUSHION RECESS F(No-WL)			•	•	•	





- This parts list contains two different types of parts. The first type is the parts that are common to all models. The other type is the parts that are different depending on each model.
- This model that is accompanied by asterisk (*) is the CTO model.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- 機種名に(*)がつくのは CTO モデルです。

B-3. Bottom (15.4-inch Model)



B-3. Bottom (15.4-inch Model)

Ref.No.	Part No.			Description
7 501 502 504 507	4-682-423-01 A-1058-406-A A-1058-416-A A-8068-827-A 4-682-454-01	\$		SE1 SPONGE BT CABLE(26P), FLEXIBLE FLAT CABLE, ODD EJECT COMPLETE PWB CNX-247 SE1 15S BATT BUTTON
508 509 510 511 512	4-682-455-01 4-682-460-01 4-682-457-01 4-683-040-01 4-682-443-01		&	SE1 15S BATT BUTTON3 SE1 15S DOOR DOCK SE1 BATT LOCK SE1 DOCKING HOOK MYLAR SE1 FOOT FRONT
513 514 515 516 517	4-682-444-01 4-682-445-01 4-682-456-01 4-682-459-01 4-682-479-01		&	SE1 FOOT REAR SE1 LATCH BATT SE1 LATCH BATT SPRING SE1 EMI SPRING BATT
518 519 520 523 524	4-682-458-02 4-682-476-01 2-103-697-01 X-4626-721-1 X-4626-653-1		& &	SE1 LATCH LEVER SE1 SW BRACKET SE1P HDD MYLAR SE1 DOOR I/O ASSY SE1 DIMM DOOR ASSY
525 526 527 543 544	X-4626-720-1 2-025-132-01 4-682-466-01 A-8068-825-A A-1058-429-A			SE1 BATTERY DOOR ASSY LABEL BATTERY SE1 15S DOOR MODEM COMPLETE PWB CNX-245 PWB(20P),FLEXIBLE PRINT
545 547 550 604 605	4-682-462-01 2-067-843-01 2-159-787-01 A-8068-829-A 4-682-418-01	\$#		SE1 15S MODEM R EMI SPRING HDD SE1 SPONGE LENS COMPLETE PWB IFX-324 SE1 BRACKET HDD
701 702 703	2-050-888-01 2-050-865-01 X-2021-745-1			SEM SHEET AUDIO BD SEM DISPLAY BASE SEM BOTTOM CASE ASSY
B1 B3 B4 B5 B7	4-672-836-01 4-672-834-41 2-048-596-02 4-672-836-11 4-644-637-21		<&> <&> <&>	SCREW, M2 SPECIAL HEAD,EG GRIP SCREW, +B EG GRIP SCREW, +B EG GRIP SCREW, M2 SPECIAL HEAD,EG GRIP GRIP, M2 EG
B29 B11 B18 B23 B24	4-672-835-01 4-672-839-01 4-672-834-21 3-254-029-11 4-672-834-71		<&>	SCREW, M2.6+B EG GRIP HEAD,M3 FLAT SCREW, +B EG GRIP SCREW SCREW,+B EG GRIP

						J			Α	М				EU	1			AO		
Ref N	o. Part No.			Description	A51PS1*	***************************************	4260	A250	A240*	A240B*	A240P*	A290F	A295HP	A215M	A215Z	A29GP	A29SP	A29LP	A29TP	A21C
503				CABLE, WIRELESS MOUSE	-	,		+	•	•	•		 	\vdash	\vdash	 	\vdash	$\overline{}$	$\overline{}$	╁
528				SE1 LENS PANEL CTO (W/WL,W/BT)			+	+	Ť	Ť	Ť		•	•	\vdash	 	\vdash	$\overline{}$	$\overline{}$	╁
020	4-682-449-11			SE1 LENS PANEL CTO(W/WL,No-BT)		,	•	•	•	•	•	•	Ť	Ť	•	•	•	•	•	H
	4-682-449-21			SE1 LENS PANEL CTO(No-WL,No-BT)		+	-	_	•	•	•	_	_		H	Ť	H		Ť	H
704				SEM BUTTON COVER RF(W/W-Mouse)	-	, ,	•	-	•	•	•				_		\vdash		_	t
705				SEM PANEL RF CTO(No-W-Mouse)		+	1	•	•	•	•	•	•	•	•	•	•	•	•	t
706	2-050-873-01			SEM BUTTON RF(W/W-Mouse)		,	•	\top	•	•	•		\vdash		-		\vdash		_	t
532	4-682-583-01			SE1P SPRING RF KNOB(W/W-Mouse)		, (•		•	•	•				\vdash		\vdash		_	t
533	1-796-949-11			USB RF MOUSE RECEIVER	-	, (•		•	•	•				_				_	t
534	A-8067-943-A	\$	#	ASSY HDD 80GB (I,40) (S)		, (• •	•	•	•	•				\vdash		М		_	t
	A-1062-140-A	\$	#	HDD (80GB,HTS548080M9AT00) (S)	•	•	•		•	•	•								$\overline{}$	t
	A-1065-272-A	\$	#	HDD (MK6025GAS-60GB) (S)			\neg			\top					$\overline{}$	•	•	•	•	t
	A-1065-502-A	\$	#	ASSY HDD 60GB(-21)(I,40)(S)	•	•	•		•	•	•	•	•	•	•				$\overline{}$	t
	A-1083-188-A	\$	#	HDD (MHU2100AT-100GB) (S)	•	•	•		•	•	•									İ
	A-1083-189-A	\$	#	HDD (MHT2080AT-80GB) (S)	•	•	•												$\overline{}$	Ī
	A-1083-186-A	\$	#	HDD(40GB,HTS424040)(S)	•	•	•		•	•	•								_	ſ
539	1-805-554-11			BLUETOOTH MODULE									•		•				_	T
540	A-1058-407-A			CABLE,BT ANTENNA									•		•				$\overline{}$	T
548	4-682-446-01			SE1 SWICH W LAN(W/WL)	•	, (•	•	•	•	•	•	•	•	•	•	•	•	•	T
549	4-682-448-01			SE1 ESCUSHION RECESS F(No-WL)					•	•	•								$\overline{}$	T
					[MA]							[MA] №						[MA] [≽	[MA] [≫	-

- 1) The parts of Ref.539 and Ref.540 are used in the BLUETOOTH installation models.
- 2) Ref.503, 704, 706, 532 and Ref.533 are used only in the models supplied with the Wireless-Mouse.
- 1) Ref.539 と Ref.540 は、BLUETOOTH 搭載モデル用の部品です。
- 2) Ref.503, 704, 706, 532, 533 は、Wireless-Mouse 付モデル用の部品です。
- This parts list contains two different types of parts.
 The first type is the parts that are common to all models.
 The other type is the parts that are different depending on each model.
- This model that is accompanied by asterisk (*) is the CTO model.
- ●この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- 機種名に(*)がつくのは CTO モデルです。


 \triangle [MA]


D-1. Optical Drive


How to Use Parts Differently.


This series of product uses the five diffrent types of the optical drive.

When replacing the optical drive, check the indication label of it, and use the same type of the optical drive. Each optical drive has different types of the bezel. For the how to identify the type of drive and the combination of the Bezel, refer to the details below.











D-1. Optical Drive

Ref.No.	Part No.	<u>Description</u>
802	4-682-408-01	SE1 CD BRACKET BACK
803	4-682-406-01	SE1 CD BRACKET L
804	4-682-407-01	SE1 CD BRACKET R
809	2-102-385-01	SE1 GASKET ODD
B5	4-672-836-11	SCREW, M2 SPECIAL HEAD 🔥
B17	4-671-538-01	SCREW(M2x4), SPECIAL HEAD 🛣
		A




- This parts list contains two different types of parts.
 The first type is the parts that are common to all models.
 The other type is the parts that are different depending on each model.
- This model that is accompanied by asterisk (*) is the CTO model.
- ●この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- 機種名に(*)がつくのは CTO モデルです。



L-1. LCD 17-inch WUXGA (Clear Black LCD) – Made by SH–


Ref.No.	Part No.		<u>Description</u>
	4-682-380-01 A-8119-991-A X-4626-664-1 4-682-397-01 4-682-396-01		SE1 COVER HINGE HARNESS, LCD FOR 17WUXGA SE1P BEZEL DISPLAY 17 ASM SE1 CUSHION LCD SIDE SE1 CUSHION LATCH
1007 1008 1009 1010 1011	4-682-395-01 4-682-398-01 4-682-388-01 4-682-390-02 2-024-790-01		SE1 CUSHION LCD SE1 COVER SCREW SE1 HOOK PLATE LCD 2 HOOK LCD 15 SE1 GASKET AU LVDS DISPLAY
	A-1062-138-A \$ # 4-682-578-01 4-682-577-01 X-4626-663-1 4-682-576-01		LCD_UNIT_(2CFL-17WUXGA)(S) SE1P HINGE L AMS SE1P HINGE R AMS SE1P HOUSING DISPLAY 17 2 ASM SE1P LCD BRACKET L
1020	2-190-716-01		SE1P LCD BRACKET R INVERTER UNIT(2CFL-17W) SE1P INVERTER ADHESIVE SE1P HOUSING AL L SE1P HOUSING AL R
1023	2-190-718-01		SE1P HOUSING AL BTM
	4-672-836-01 4-672-836-21 4-672-836-11 4-671-538-01 2-108-227-01	<&>	SCREW, M2 SPECIAL HEAD,EG GRIF SCREW, M2 SPECIAL HEAD,EG GRIF SCREW, M2 SPECIAL HEAD,EG GRIF SCREW(M2x4),SPECIAL HEAD SPECIAL FLAT HEAD

				J			ΑM	1		ВJ	AO
				A71PS*	A71S*	A290	A270*	A270B*	A270P*	A297XP	A29CP
	Ref.No.	Part No.	Description							٦.	ļ
	1002	A-1058-425-A	CABLE, WL ANTENNA	•	•	•	•	•	•	•	•
[MA]	1012	2-320-133-01	LABEL ID (E)							•	
-		2-320-341-01	LABEL ID (U)			•					
[MA] [MA] [MA]		2-320-350-01	LABEL ID (JCTO)	•							
[MA]		2-320-350-11	LABEL ID (J CTO)		•						
[MA]		2-320-353-01	LABEL ID (UCTO)						•		
[MA]		2-320-353-11	LABEL ID (UCTO)				•				
[MA]		2-320-353-21	LABEL ID (UCTO)					•			
[MA]		2-320-356-01	LABEL ID (C)								•



- This parts list contains two different types of parts.
 The first type is the parts that are common to all models.
 The other type is the parts that are different depending on each model.
- This model that is accompanied by asterisk (*) is the CTO model.
- ●この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- 機種名に(*)がつくのは CTO モデルです。

VGN-A215M/A215Z/A217M/A217S/A295HP/A297XP VGN-A21C/A23CP/A29CP/A29GP/A29LP/A29SP/A29TP



L-2. LCD 17-inch WXGA+ (Clear Black LCD) - Made by AU-

Ref.No.	Part No.		<u>Description</u>
1001	4-682-380-01		SE1 COVER HINGE
1005	4-682-397-01	-	SE1 CUSHION LCD SIDE
1006	4-682-396-01	&	
1007	4-682-395-01		SE1 CUSHION LCD
1008	4-682-398-01	&	SE1 COVER SCREW
1009	4-682-388-01		SE1 HOOK PLATE LCD 2
1010	4-682-390-02		HOOK LCD 15
1011	2-024-790-01		SE1 GASKET AU LVDS DISPLAY
	4-682-578-01		SE1P HINGE L AMS
1015	4-682-577-01		SE1P HINGE R AMS
1016	X-4626-663-1		SE1P HOUSING DISPLAY 17 2 ASM
1019	1-478-629-11		INVERTER UNIT(2CFL-17W)
1020	2-159-645-01		SE1P INVERTER ADHESIVE
1021	2-190-716-01		SE1P HOUSING AL L
1022	2-190-717-01		SE1P HOUSING AL R
1023	2-190-718-01		SE1P HOUSING AL BTM
1051	X-2024-399-1		SE2P BEZEL DISPLAY 17 AU
1052	A-1074-808-A		HARNESS,LCD 17 WXGA
1053	2-176-382-01		SE2P LCD BRACKET L
1054	2-176-383-01		SE2P LCD BRACKET R
1055	A-1087-141-A	\$#	LCD UNIT (17WXGA) (S)
1056	2-342-994-01		SHIELD TAPE(AU17)
B1	4-672-836-01		SCREW, M2 SPECIAL HEAD,EG GRIP
B2	4-672-836-21		SCREW, M2 SPECIAL HEAD,EG GRIP
B5	4-672-836-11	<&>	SCREW, M2 SPECIAL HEAD, EG GRIP
	4-671-538-01		SCREW(M2x4),SPECIAL HEAD
B22	2-108-227-01		SPECIAL FLAT HEAD
1055 1056 B1 B2 B5 B17	A-1087-141-A 2-342-994-01 4-672-836-01 4-672-836-21 4-672-836-11 4-671-538-01		LCD_UNIT_(17WXGA)_(S) SHIELD TAPE(AU17) SCREW, M2 SPECIAL HEAD,EG GRIP SCREW, M2 SPECIAL HEAD,EG GRIP SCREW, M2 SPECIAL HEAD,EG GRIP SCREW(M2x4),SPECIAL HEAD

	[JF	,		AM		E	U
				A 194	A71S*	A71PS*	A270*	A270B*	A270P*	A217S	A217M
		Ref.NcPart No.	Description								
		1002 A-1058-425-A	CABLE, WL ANTENNA	•	•	•	•	•	•	•	•
◬	[MA]	1012 2-320-133-11	LABEL ID (E)							•	\Box
		2-320-133-21	LABEL ID (E)								•
Δ	[MA]	2-320-340-01	LABEL ID (J)		•						
		2-320-353-01	LABEL ID (UCTO)						•		
		2-320-353-11	LABEL ID (UCTO)				•				
		2-320-353-21	LABEL ID (UCTO)					•			
Δ	[MA]	2-320-350-01	LABEL ID (JCTO)		•						
\triangle	[MA]	2-320-350-11	LABEL ID (JCTO)			•					
		This parts list contains two differe	ent types of parts.		MA ∑	[MA]				[MA] [≫	


• This parts list contains two different types of parts. The first type is the parts that are common to all models.

The other type is the parts that are different depending on each model.

- This model that is accompanied by asterisk (*) is the CTO model.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- 機種名に(*) がつくのは CTO モデルです。


⚠[MA]

L-3. LCD 15-inch SXGA+ (Clear Black LCD)



L-3. LCD 15-inch SXGA+ (Clear Black LCD) – Made by SH–


Ref.No.	Part No.		<u>Description</u>
609 1001 1005 1006 1007	4-672-493-01 4-682-380-01 4-682-397-01 4-682-396-01 4-682-395-01	&	COVER(SC) SE1 COVER HINGE SE1 CUSHION LCD SIDE SE1 CUSHION LATCH SE1 CUSHION LCD
1008 1009 1010 1011 1101	4-682-398-01 4-682-388-01 4-682-390-01 2-024-790-01 X-4626-643-1	&	SE1 COVER SCREW SE1 HOOK PLATE LCD 2 SE1 HOOK LCD 15 SE1 GASKET AU LVDS DISPLAY SE1 BEZEL DISPLAY 15 ASSY
1102 1103 1104 1105 1106	A-8119-992-A 4-682-402-01 4-682-403-01 1-478-048-11 A-1062-139-A \$ #	ŧ	HARNESS, LCD FOR 15SXGA+ SE1 BRACKET LCD SH L SE1 BRACKET LCD SH R INVERTER UNIT LCD UNIT (2CFL-15SXGA+-SH)(S)
1107 1108 1109 1110 1111	X-4626-642-1 4-682-405-01 4-682-404-01 2-024-789-01 4-682-391-01		SE1 HOUSING DISPLAY 15 ASSY SE1 HINGE R SE1 HINGE L SE1 TAPE LVDS DISPLAY SE1 SHEET LCD
B1 B5 B7 B15 B17	4-672-836-01 4-672-836-11 4-644-637-21 4-653-582-21 4-671-538-01		SCREW, M2 SPECIAL HEAD,EG GRIP SCREW, M2 SPECIAL HEAD,EG GRIP GRIP, M2 EG SCREW M2(NE) SCREW(M2x4),SPECIAL HEAD
B22	2-108-227-01		SPECIAL FLAT HEAD(EG GRIP)



[MA]

- This parts list contains two different types of parts.
 The first type is the parts that are common to all models.
 The other type is the parts that are different depending on each model.
- This model that is accompanied by asterisk (*) is the CTO model.
- ●この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- 機種名に(*) がつくのは CTO モデルです。

L-4. LCD 15-inch XGA



VGN-A51PS1/A51PS2/A51S1/A51S2/A61B/A71PS/A71S VGN-A230/A230B/A230P/A240/A240B/A240P/A250/A260/A270B/A270B/A270P/A290F/A290F VGN-A215M/A215Z/A217M/A217S/A295HP/A297XP VGN-A21C/A23CP/A29CP/A29GP/A29LP/A29SP/A29TP


L-4. LCD 15-inch XGA - Made by AU-

Ref.No.	Part No.			Description
609	4-672-493-01			COVER(SC)
1001	4-682-380-01			SE1 COVER HINGE
1005	4-682-397-01		&	SE1 CUSHION LCD SIDE
1006	4-682-396-01		&	SE1 CUSHION LATCH
1007	4-682-395-01		&	SE1 CUSHION LCD
1008	4-682-398-01		&	SE1 COVER SCREW
1009	4-682-388-01			SE1 HOOK PLATE LCD 2
1010	4-682-390-01			SE1 HOOK LCD 15
1011	2-024-790-01			SE1 GASKET AU LVDS DISPLAY
1101	X-4626-643-1			SE1 BEZEL DISPLAY 15 ASSY
1107	X-4626-642-1			SE1 HOUSING DISPLAY 15 ASSY
1108	4-682-405-01			SE1 HINGE R
1109	4-682-404-01			SE1 HINGE L
1110	2-024-789-01			SE1 TAPE LVDS DISPLAY
1111	4-682-391-01			SE1 SHEET LCD
1201	A-8119-993-A			HARNESS, LCD FOR 15XGA
1202	4-682-400-01			SE1 BRACKET LCD SPWG L
1203	4-682-401-01			SE1 BRACKET LCD SPWG R
1204	A-8115-791-A \$	#		ASSY LCD 15XGA(AU)(S)
1205	1-476-316-31			INVERTER UNIT
B1	4-672-836-01			SCREW, M2 SPECIAL HEAD,EG GRIP
B5	4-672-836-11		<&>	SCREW, M2 SPECIAL HEAD, EG GRIP
B7	4-644-637-21			GRIP, M2 EG
B15	4-653-582-21		<&>	SCREW M2(NE)
B17	4-671-538-01			SCREW(M2x4),SPECIAL HEAD
B22	2-108-227-01			SPECIAL FLAT HEAD(EG GRIP)

[AM		ΑO
	Ref.No. Part No.	Description	A230*	A230B*	A230P*	A23CP
ŀ	1012 2-320-353-61	LABEL ID (UCTO)		-	_	₩
- 1				-	•	⊢
١	2-320-353-71	LABEL ID (UCTO)				
- 1	2-320-353-81	LABEL ID (UCTO)	- 1	•		
A][2-320-356-11	LABEL ID (C)				•
1	1112 A-1058-421-A	CABLE, WL ANTENNA	•	•	•	•

• This parts list contains two different types of parts. The first type is the parts that are common to all models.

- This model that is accompanied by asterisk (*) is the CTO model.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- ●機種名に(*)がつくのは CTO モデルです。



L-5. LCD 15.4-inch WXGA (Clear Black LCD)

- Made by HI-


Ref.No.	Part No.		<u>Description</u>
609	4-672-493-01		COVER(SC)
1001	4-682-380-01		SE1 COVER HINGE
1005	4-682-397-01	&	SE1 CUSHION LCD SIDE
1006	4-682-396-01	&	SE1 CUSHION LATCH
1007	4-682-395-01	&	SE1 CUSHION LCD
1008	4-682-398-01	&	SE1 COVER SCREW
1011	2-024-790-01		SE1 GASKET AU LVDS DISPLAY
1108	4-682-405-01		SE1 HINGE R
1109	4-682-404-01		SE1 HINGE L
1301	A-1067-140-A		HARNESS, LCD FOR 15.4WXGA
1302	X-2021-749-1		SEM BEZEL DISPLAY ASSY
1303	2-050-879-01		SEM LCD HOOK
1304	A-1072-741-A \$ #		ASSY LCD(15.4WXGA)(H)(S)
1305	X-2021-750-1		SEM HOUSING DISPLAY ASSY
1306	2-050-880-01		SEM LCD BRACKET L
1307	2-050-881-01		SEM LCD BRACKET R
1308	1-478-040-11		INVERTER UNIT
1309	2-050-890-01		SEM LCD SHIELDING AL
1110	2-024-789-01		SE1 TAPE LVDS DISPLAY
1312	4-677-681-01		SR1 SPONGE DOOR BATTERY
1313	2-515-223-01		SPONGE LCD
B5	4-672-836-11	<&>	SCREW, M2 SPECIAL HEAD,EG GRIP
B6	4-656-703-01		SCREW,M2 GRIP
B7	4-644-637-21		GRIP M2 EG
B15	4-653-582-21	<&>	SCREW M2(NE)
B22	2-108-227-01		SPECIAL FLAT HEAD(EG GRIP)

						J				AM					BU				ΑO		
		Ref.No.	Part No.	Description		A51PS1*	A51S1*	A260	A250	A240*	A240B*	A240P*	A290F	A295HP	A215M	A215Z	A29GP	A29SP	A29LP	A29TP	A21C
			A-1067-141-A		ANTENNA FOR M	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
		1012	2-320-341-11	LABEL ID (U				•					\neg	\neg †	一					\neg	\neg
			2-320-341-21	LABEL ID (U)				•	\neg			\neg							\neg	\neg
			2-320-345-01	LABEL ID (E	.)									•							
			2-320-345-11	LABEL ID (E	.)										•						
			2-320-345-31	LABEL ID (E												•					
	[MA]		2-320-350-21	LABEL ID (J)		•															
	[MA]		2-320-350-31	LABEL ID (J)		•														
			2-320-353-31	LABEL ID (U	CTO)							•									
			2-320-353-41	LABEL ID (U	CTO)					•											
			2-320-353-51	LABEL ID (U							•										
	[MA]		2-320-354-01	LABEL ID (L)								•								
	[MA]		2-320-356-21	LABEL ID (C	:)																•
			2-320-361-01	LABEL ID (I)													•				
			2-320-361-11	LABEL ID (I)														•			
	[MA]		2-320-361-21	LABEL ID (I)															•		
-	[MA]		2-320-361-31	LABEL ID (I)																•	
						A	A	•		-			A			-	•	•	Α	$\overline{\wedge}$	<u></u>
						4	4					- 4	<u>2</u>						4	4	◬

This parts list contains two different types of parts.
 The first type is the parts that are common to all models.
 The other type is the parts that are different depending on each model.

- This model that is accompanied by asterisk (*) is the CTO model.
- ●この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- 機種名に(*)がつくのは CTO モデルです。
- 1) The CABLE,WL ANTENNA FOR M(Ref.1310) is installed also in the models without Wireless LAN. Refer to "5-3 Wiring the W-LAN Cable" in CHAPTER 5 to see how to wire the CABLE.
- 1) Wireless-LAN を搭載しないモデルにも、CABLE,WL ANTENNA FOR M (Ref.1310) が取りつけられています。 ケーブルの処理方法は CHAPTER 5、「5-3 Wiring the W-LAN Cable」を参照してください。

A-1. Accessories



Refer to A-2.Accessories


			1 -			J									A۸	1								В	J		Т			AO			_
			A51PS1*	*	32*	*	_	%	*0	*	*	<u>*</u>	*	* a			*	B*	<u>*</u>		Ľ.	Σ	Ņ	≥ 9	A21/S A295HP	: <u> </u>		ۻ	ĕ	ب	بــ	۵	_
			19,1	A51S1	A51PS2*	A51S2*	A61B	A71PS	A71S*	A230*	A230B*	A230P*	A240*	A240B	A240P	A260	A270*	A270B*	A270P*	A290	A290F	A215M	A215Z	A217M	A21/S A295HP	A297XP	A21C	A23CP	A29CP	A29GP	A29LP	A29SP	3
	Defair Destair	Description	A5	¥	A5	Ι¥Ι		Ϋ́	⋖	⋖	8	₹	⋖	¥ ۶	₹ ~	~	<	AS	AS	~	4	¥	4	۶ ۰	4 ≥	! ₩	•	¥	¥	¥	A	ΙŽ	-
ΠΛΛΔ1	Ref.No. Part No. A 2001 1-477-205-81 \$	Description & ADAPTOR, AC	-	•	•			•	•	•	•	•	•	•		+	•	•	•	\dashv	•	•	•	•	١.		•	•	+	•	•		+
[ivi/s]	△ 2011 1-477-203-81 \$	& ADAPTOR, AC	-	•	•			•	•	•	•	•	•	•	_		•	•	•	•	-	-	-	_	•	+	+	Ť	•	Ť	+	Ť	+
ΠΛΛΔ1	△ 2002 A-1062-155-A \$	& BATTERY 9130PA SNT(J)(S)	•	•	•	•	•	•	•	Ť	-	Ť	-	+	+	Ť	Ť	-	Ť	-	_	_	+	+	+	+	+	+	Ť	\vdash	+-	+	+
[ivi/s]	△ 2002 A-1062-193-A \$	& BATTERY_9130PA_(U)(S)	+-		•	H		•	-	•	•	•	•	•		•	•	•	•	•	_	_	+	+	+	+	+	+	+	\vdash	+	+	-
ΠΛΛΔ1	₾ 2002 A-1062-142-A \$	& BATTERY_9130PA_(E)(S)	\dashv			\vdash		_	\dashv	Ť	Ť	-	•	-	+	Ť	Ť	Ť	_	-	•	•	•	•				•	•	•	•		-
[MA]	△ 2002 A-1002-143-A \$	& CORD, POWER	+	H		\vdash		\dashv	\dashv	-	\dashv	_	\dashv	+		+				\dashv	-	_	+	-	+	Ť	Ť	Ť	Ť	•	Ť	Ť	-
[MA]		& CORD, POWER	+	\vdash		\vdash	\vdash	\dashv	\dashv	_	\dashv	\dashv	\dashv	+	+	+				\dashv	\dashv	•	•	•	• •		+	+	\vdash	Ť	\vdash	١.	-
[iva d	△ 2003 1-757-562-21	& CORD, POWER	\dashv			\vdash		_	\dashv	•	•	•	•	•		•	•	•	•	•	•	Ť	Ť	+	+	Ť	+	+	+	\vdash	+	Ť	-
	△ 2003 1-782-476-22	& CORD, POWER	$\dashv \dashv$			\vdash		_	\dashv	Ť	Ť	-	•	-	+	Ť	Ť	Ť	_	-	Ť	_	_	+	+	+	•	•	•	\vdash	+	+	-
[MA]	△ 2003 1-762-476-22 △ 2003 1-829-237-21	& CORD, POWER	$\dashv \dashv$			\vdash		_	\dashv	\dashv	_	_	_	+		1	\vdash		\vdash	\dashv	\dashv	_	_	+	+	+	Ť	Ť	Ť	\vdash	+	+	-
[MA]	△ 2003 1-790-732-32	& CORD, POWER	٠.	•	•	•	•	•	•	\dashv	_	_	_	+		1	\vdash		\vdash	\dashv	\dashv	_	_	+	+	+	+	+	+	\vdash	+	+	-
[MA]	2004 1-823-935-51	& CORD, AC POWER(GB)	+-	H	_	H	H	-	-	-	\dashv	_	\dashv	+		+				\dashv	+	•	•	•			+	+	+	•	+	+	-
[ivi/s]	2004 1-829-239-11	& CORD, F TERMINAL WITH RF	•	•	•	•	•	•	•	•	•	•	•	•			•	•	•	•	\dashv	-	•	-	•	+•	+	+	•	Ť	+	+	-
[MA]		& ADAPTOR, CONVERSION PLUG 3P	+	H	Ť	H	H	-	-	Ť	-	-	-	-	+	Ť	Ť	Ť	Ť	-	\dashv	•	+	_	• •		+	+	Ť	\vdash	+	+	-
[MA]		· · · · · · · · · · · · · · · · · · ·	+	H		\vdash		\dashv	\dashv	-	-	-	-	-			+		+	\dashv	+	•	\dashv	•	`	+•	+	+	+-	+	•	+	-
[MA]	2007 1-823-947-32 2008 1-816-429-12	& POWER-SUPPLY CORD & PHONE PLUG (GB)	$+\!\!-\!\!\!-$	\vdash		\vdash		\dashv	\dashv	-	-	-	-	-						\dashv	-	•	•	•			+	+	+	+-	+	+	-
[IVIA]			-	•	•		•	•	•	•	•	•	•	•	_	•	•	•	•	•	-	•	•	-	•	┿	+	+-	•	\vdash	+	+	-
	2009 A-1077-876-A 2010 -	& ASSY SPEAKER FW & PORT REPLICATOR		•	•	•	•	-	-	•	•			_	•	•	_	•	•	•	\dashv	\dashv	+	_	•	+	+	+	•	\vdash	+-	+	-
			┯	-	•	-	•	•	-	•	•	•	-	•	_	٠.	_	•	•		\dashv	\dashv	+	+	' +	+	+	+	+•	\vdash	+	+	•
D 441	2020 1-478-300-21	& IR COMMANDER RM-GP5U	+-		_	Н		_	_	•	•	•	•	•	•	+•	·	•	•	•	-	-	\dashv	+	+	+	+	+	+-	\vdash	+	+	
[MA]	2021 1-478-615-11	& MEMORY CARD ADAPTER	•	•	•	•	•	•	•	-	\dashv	-	•	•	_		١.	•	_	\dashv	-	-	\dashv	+	+	+-	+	+-	•	\vdash	+-	+	
	2022 1-796-824-32	& MOUSE (SLV)	•		_	\vdash	•	•	-		\dashv	-	•	• '	•		•	•	•	\dashv	-	-	\dashv	'	•	•	+	+-	+-	\vdash	+	+	
[MA]	2023 1-478-688-11	& REMOTE COMMANDER (RM-VC10)	•	•	•	•	•	•	•	-	\dashv		-	-			-			\dashv	_	-	+	_	+	+	+	+-	₩	\vdash	+-	+	
D 443	2024 1-478-969-11	& REMOTE COMMANDER (RM-VC10E)	$+\!\!\!-$	\vdash		\vdash		\dashv	\dashv	-	-	\dashv	\dashv	+	_	+	-			\dashv	\dashv	-	\dashv	+	•	+	+	+	+-	⊢	+	╀	•
[MA]	2025 1-479-090-11	& REMOTE COMMANDER	+-	•		Н		_	_	-	-	-	-	+	-	+	+			\dashv	-	-	\dashv	+	+	+	+	+	•	\vdash	+	+	-
[MA]	- 2-318-131-01	& MANUAL (XP), INSTRUCTION(J)	•	-	•	•	•	•	•	-	-	-	-+	+	+.	+.	-		-	_	-	-	\dashv	+	+	+	+	+	+	\vdash	+	+	-
D 441	- 2-345-501-01	& QUICK START	+	\vdash		\vdash		\dashv	\dashv	-	\dashv	-	\dashv	-	•	•	-			•	_	-	\dashv	+	+	+	+	+-	+-	\vdash	+-	+	
[MA]	- 2-320-821-01	& QUICK START	+	\vdash		\vdash		\dashv	\dashv		\dashv	-	-	-			-			\dashv	•	-	+	_	+	+-	+	+-	+-	\vdash	+-	+	
[MA]	- 2-318-632-01	& GETTING STARTED BOOKLET	$+\!\!\!-$	\vdash		\vdash		\dashv	\dashv	-	\dashv	\dashv	\dashv	+	-	+	\vdash		-	\dashv	-	\dashv	-	•	•	•	+	+	\vdash	₩	\vdash	+	
[MA]	- 2-318-840-01	& GETTING STARTED BOOKLET(C)	4	\vdash		\vdash		-	\dashv	_	_	_	_	_	_	-	-			\dashv	-	•	•	_	•	4	₩	₩	₩	—	₩	+	•
[MA]	2-320-668-21	& SAFETY/REGULATIONS GUIDE	+	\vdash		\vdash		-	\rightarrow	_	-	_	_	+	_	_	\vdash			\dashv	_	-	\rightarrow	+	+	+	₩	₩	₩	₩	•	+	
[MA]	2-320-668-41	& SAFETY/REGULATIONS GUIDE	+	\vdash		\vdash		_	\rightarrow	_	-	_	_	+	_	_	\vdash			\dashv	_	-	\rightarrow	+	+	+	₩	₩	₩	₩	₩	+	
[MA]	- 2-320-674-31	& SAFETY/REGULATIONS GUIDE	+	\vdash		ш		_	_	_	_	_	_	_			-			_	_	_	\rightarrow	_	+	+	•	•	•	₩	₩	+	
[MA]	2-320-669-21	& TROUBLESHOOTING GUIDE	—	\vdash		\vdash		-	_	_	-	_	-	+	_	-	\vdash			\dashv	_	-	\rightarrow	+	+	+	₩	₩	₩	—	•	+	
[MA]	2-320-669-41	& TROUBLESHOOTING GUIDE	——	\vdash		ш		_	_		_	_	_	_	_	_	-			_	_	_	\rightarrow	_	+	+	₩	₩	₩	₩	₩	\perp	
[MA]	- 2-320-675-31	& TROUBLESHOOTING GUIDE		\vdash		\vdash		_	_		_	_	_	+	_	-	-			_	_	4	_	_	+	+	•	•	•	—	₩	_	
[MA]	- 2-318-627-11	& HW SPECS (GB,NL)		\vdash		ш		_	_	_	_	_	_	+	_	_				_	_	_	\rightarrow	_	•	•	_	₩	₩	₩	₩	\perp	
[MA]	- 2-318-627-21	& HW SPECS(DE)		\vdash		ш		_	_	_	_	_	_	+	_	_				_	_	_	-	_	•	•	_	₩	₩	₩	₩	\perp	
[MA]	- 2-318-627-31	& HW SPECS(FR)		\vdash		ш		_	_	_	_	_	_	+	_	_				_	_	_	-	_	•	•	_	₩	₩	₩	₩	\perp	
[MA]	- 2-318-627-41	& HW SPECS(IT)		\vdash		ш		_	_	_	_	_	_	+	_	_				_	_	_	-	_	•	•	_	₩	₩	₩	₩	\perp	
[MA]	- 2-318-627-51	& HW SPECS(SE)	'	Ш		\sqcup		_	_		4	_	_	\perp		_						_	\rightarrow	_	•	•	_	╄	₩	╙	₩	\perp	
[MA]	- 2-318-627-61	& HW SPECS(NL,BE)	'	Ш		\sqcup		_	_		4	_	_	\perp		_						_	4	•	•	•	_	╄	₩	╙	₩	\perp	
[MA]	- 2-318-627-71	& HW SPECS(PT)	'	Ш		\sqcup		_	_		4	_	_	\perp		_						_	4	4	\bot	•	┷	╄	₩	╙	₩	\perp	
[MA]	- 2-342-628-11	& HW SPECS(C)(GB)	'	Ш		\sqcup		_	_		4	_	_	\perp		_						•	•	4	•	,	┷	╄	₩	╙	₩	\perp	
[MA]	- 2-342-628-21	& HW SPECS(C)(DE)	'	Ш		\sqcup		_	_		4	_	_	\perp		_						_	•	4	•	_	┷	╄	₩	╙	₩	\perp	
[MA]	- 2-342-628-31	& HW SPECS(C)(FR)	'	Ш		\sqcup		_	_		4	_	_	\perp		_						•	4	4	•	-	┷	╄	₩	╙	₩	\perp	
[MA]	- 2-342-628-41	& HW SPECS(C)(IT)	'			Ш		_	_		_									_	_	•	•	_	•	_		╙		╙		┸	
[MA]	- 2-342-628-61	& HW SPECS(C)(NL)	'	Ш		ш																•	_	\perp	•	,	\perp	\perp				\perp	
[MA]	- 2-342-628-51	& HW SPECS(C)(ES)	'	Ш		Ш	Ш		_		_	_		\perp		\perp	_					•	4	4	•	_	1	₩	₩	\vdash	₩	\perp	
[MA]	- 2-342-628-71	& HW SPECS(C)(EPT)	لــــــــــــــــــــــــــــــــــــــ	Ш		Ш																			_ •		丄	Ш	Ш	Щ	Ш	上	
			[MA]	Α	Δ	[MA]	[MA]	Δ	[MA]	[MA]	Α.	A.	A.	A /	MA	A	. 1	[MA]	A		[MA]	ſΜΑ] Ψ	Δ.∠ [MA]	î. ∠	[MA]	\ A	[MA]	[MA]	[MA]	[MA]	[MA]	[MA]	٠
				~~	\sim		_																										

- •1) The Ref.2005,2009,2010,2011,2020 and 2023 are included only in the models supplied with the Port Replicator.
- ●1) Ref.2005,2009,2010,2011,2020, 2023 は、Port Replicator 同梱機種のみについてきます。

Confidential

- This model that is accompanied by asterisk (*) is the CTO model.
- ●機種名に(*)がつくのは CTO モデルです。

VGN-A21C/A23CP/A29CP/A29GP/A29LP/A29SP/A29TP



A-2. Accessories

Ref.No.	Part No.		Ref.No	
1 2	X-4626-667-1 4-682-689-01		SUB HOUSING UPPER BPR ASSY BPR MYLAR FOOT	62
3	4-682-693-01		BPR CAP BOSS DOCK CONN	B31
4	4-682-694-01		BPR BRACKET ARM TRAY	B32
5	4-682-695-01		BPR HOOK FRONT	B33
•	4 000 007 01		DDD ADM CLIDE HOOK YOKO	B34
6 7	4-682-697-01 4-682-698-01		BPR ARM SLIDE HOOK YOKO BPR KNOB HOOK RELEASE	B35
8	4-682-699-01		BPR KNOB HOOK RELEASE BOTTON	B36
9	4-682-700-01		BPR PIN GND	B37
10	X-4626-672-1		SUB HOUSING TRAY BPR ASSY	B38
44	4 000 701 01		BPR CUSHION REAR	
11 12	4-682-721-01 4-682-720-01		BPR CUSHION FRONT	
13	2-048-435-01	α	BPR MYLAR FPC	
14	A-1058-415-A		HARNESS, DC	
15	A-1059-670-A \$		COMPLETE PWB CNX-271	

16	4-682-690-01		BPR PLATE DOCK CONN UPPER	
17	4-682-691-01		BPR PLATE DOCK CONN BOTTOM	
18	2-048-436-01		BPR MYLAR SHIELDING	
19	X-2021-564-1		BPR ASSYSUB CAM SLIDE HOOK	
20	2-048-437-01		BPR SPONGE CAM SLIDE HOOK	
21	4-682-709-01		BPR ARM TRAY PIN	
22	4-682-712-01		BPR BRACKET DC	
24	4-682-708-01		BPR LIGHT GUIDE LED	
25	4-682-714-01		BPR SPRING TRAY R	
26	4-682-715-01		BPR SPRING TRAY L	
28	X-4626-669-1		SUB HOUSING BOTTOM BPR ASSY	
29	4-682-703-01	&	BPR RUBBET FOOT	
30	2-048-440-01		APR MYLAR B2B CONNECTOR	
32	X-4626-671-1		SUB FRAME BPR ASSY	
33	4-682-710-01		BPR COVER RIGHT HOUSING UPPER	
34	4-682-711-01		BPR COVER LEFT HOUSING UPPER	
35	A-1058-418-A		PWB (60P), FLEXIBLE PRINT A	
36	A-1058-419-A		PWB (60P), FLEXIBLE PRINT B	
37	A-1058-420-A		CABLE, ETHER	
40	4-682-728-01		APR COVER BRACKET D-SUB-1	
41	4-682-729-01		APR COVER BRACKET D-SUB-2	
42	2-048-439-01		BPR ENFORCE PLATE	
43	2-103-312-01		MYLAR TOP SHIELD R	
45	2-103-314-01		MYLAR 34x40	
47	2-103-316-01		GASKET 7x10x2	
48	2-103-317-01		MYLAR HOOK FRONT	
50	2-103-318-01		APR FOIL AL 6x24	
51	A-1059-668-A \$		COMPLETE PWB IFX-312	
60	2-048-434-01		BPR MYLAR BRACKET ARM TRAY	
61	2-103-313-01		BPR MYLAR TOP SHIELD L	

Ref.No.	Part No.	Description
62	2-148-338-01	BPR SPONGE USB 2 PORT
B31 B32 B33 B34 B35	4-635-966-01 4-671-504-11 3-906-376-01 4-639-112-31 2-103-677-01	SCREW (HEX) <&> SCREW,TAPPING+P2.6 SCREW(2.6x6) SCREW M2X4 T3X8L. (I) B-NI
B36 B37 B38	4-641-726-21 4-671-538-01 4-635-301-11	<8> SCREW(M2),SPECIAL HEAD SCREW(M2x4),SPECIAL HEAD SCREW M3X4

					J-PR	U-PR	E-PR	C-PR
		Ref.No.	Part No.	Description				
	Ì	27	A-1084-118-A	\$ COMPLETE PWB CNX-250E	•	•	•	
4	[MA]		A-1084-117-A	\$ COMPLETE PWB CNX-250C				•
	Ī	31	X-4626-673-1	SUB COVER IO AV1 APR1 ASSY	•	•	•	
	i	44	2-103-240-01	MYLAR RCA 1PIN	•	•	•	
	Ī	49	4-680-501-01	RF,CONN WASHER	•	•		
◬	[MA]	52	A-1059-662-A	\$ COMPLETE PWB ENX-29(J)	•			
	ĺ		A-1059-667-A	\$ COMPLETE PWB ENX-29(U)		•		
◬	[MA]		A-1081-799-A	\$ COMPLETE PWB ENX-34			•	
		53	4-682-722-01	APR BRACKET TUNER	•	•		
◬	[MA]	80	2-345-937-01	EPR BRACKET TUNER			•	
	Ī	54	4-680-482-01	RF CONN,NUT	•	•		
	ĺ	63	2-148-335-01	APR THERMAL PAD TUNER BIG	•	•		
		64	2-148-336-01	APR THERMAL PAD TUNER SIDE	•	•		
		65	X-2022-558-1	ASSY SUB HEATSINK TUNER	•	•		
	[66	2-148-337-01	APR ADHESIVE HEATSINK TUNER MO	•	•		
◬	[MA]	67	X-2024-177-1	APR SUB FAN BRACKET ASSY			•	
◬	[MA]	68	2-318-497-01	APR ADHESIVE FAN BRACKET			•	
Δ	[MA]	69	A-1081-380-A	UDQFUMH07-AS DC FAN 105MM			•	
Δ	[MA]	70	2-345-931-01	EPR MYLAR TUNER			•	
Δ	[MA]	71	2-318-499-01	EPR BRACKET TUNER			•	
4	[MA]	72	2-345-932-01	CPR SPACER DC				•
4	[MA]	73	2-345-933-01	CPR DUMMY BOARD				•
4	[MA]	74	X-2024-630-1	CPR COVER IO AV ASSY				•
4	[MA]	75	2-345-934-01	CPR CAP S-VIDEO				•
4	[MA]	76	2-345-935-01	CPR CAP VIDEO IN				•
	[MA]	77	2-345-936-01	CPR CAP TUNER				•
4	[MA]	78	2-345-937-01	CPR MYLAR RCA				•
			·	<u>-</u>	A		A	A






- The destination is shown in the list of 4-1 for the Port Replicator. Please refer to list shown in the below.
- ●ポートリプリケーターの仕向けは、4-1の一覧表を参照ください。

DIP Switch


The DIP switch setting is following table.

DIPスイッチの設定は下の表をご参照ください。



The DIP switch setting is different depending the types of LCD. Set the DIP switch of the CTO model in accordance with the [FOR CTO MODEL].

DIP スイッチの設定は、LCD の種類によって異なります。 CTO モデルは、【FOR CTO MODEL】の表に従って DIP スイッチを設定してください。




CHAPTER 5. **OTHERS**

5-1. The barcode label


The hatched portion of the barcode label is used as the repair data.

バーコードラベルの網掛け部は、修理データとして使用しています。


[MBX-110 Board] (Side A)



[IFX-335/IFX-324 Board] (Side B)



[HDD] (Made by Hi) (Bottom)



Α : Parts No.

В : Serial No. C : Revision No. D : Product code


Е : Maker Barcode F : Global User ID (iLink)

: Barcode


G : Mac Address

[MBX-110 Board] (Side B)


[Modem Card]




[LCD Unit] (Rear)




[Wireless LAN Card]







[Optical Drive] (Top)






5-2. Replacing the CPU


1. Removing the CPU

- ① Insert a flat-blade screwdriver into the notch as shown in the illustration and rotate it so that the protrusion comes to the lock release position.
- 2 Pull the CPU gently upward to lift it out of the CPU socket.



2. Installing the CPU

- ① Align the triangle reference mark of the CPU with that of the CPU socket and insert all the pins of the CPU to the corresponding holes of the CPU socket.
- While pressing the two positions marked by O, insert the flat head (-) screwdriver into the specified position and rotate the screwdriver to the LOCK position.





NOTE:

Rotate a flat-blade screwdriver to the lock position securely. If not, the operation of the CPU may become unstable.


5-3. Wiring the W-LAN Cable (For 15.4 WXGA Model)

* The CABLE W-LAN ANTENNA is installed also in the models without Wireless LAN. Refer to the instructions below to see how to wire the CABLE.






1. Wire the CABLE W-LAN as shown in the picture.



2. Attach the KAPTON TAPE to secure the terminal of the CABLE such that it winds around secure the terminal of the CABLE.



3. Attach the KAPTON TAPE on the top of the sheet and secure the CABLE.



VGN-A51PS1/A51PS2/A51S1/A51S2/A61B/A71PS/A71S VGN-A230/A230B/A230P/A240/A240B/A240P/A250/A260/A270/A270B/A270P/A290/A290F VGN-A215M/A215Z/A217M/A217S/A295HP/A297XP VGN-A21C/A23CP/A29CP/A29GP/A29LP/A29SP/A29TP

List of VGN-A Series (As of November, 2004)

Service Manual	Model Name						
Part No.	J	АМ	EU	AO			
	VGN-A50B	VGN-A130*	VGN-A115B	VGN-A11C			
	VGN-A60B	VGN-A130P*	VGN-A115S	VGN-A13CP			
	VGN-A60PS*	VGN-A170*	VGN-A117S	VGN-A15CP			
	VGN-A60S*	VGN-A170P*	VGN-A195EP	VGN-A15GP			
9-876-367-XX	VGN-A70P	VGN-A190	VGN-A195HP	VGN-A15LP			
3-070-307-XX	VGN-A70PS*		VGN-A197VP	VGN-A17GP			
	VGN-A70S*		VGN-A197XP	VGN-A17LP			
				VGN-A17SP			
				VGN-A17TP			
				VGN-A19CP			
		VGN-A140*	VGN-A115M	VGN-A17CP			
		VGN-A140B*	VGN-A115Z	VGN-A19GP			
9-876-374-XX		VGN-A140P*		VGN-A19LP			
		VGN-A150		VGN-A19SP			
		VGN-A160		VGN-A19TP			
		VGN-A190F					
	VGN-A51PS1*	VGN-A230*	VGN-A215M	VGN-A21C			
	VGN-A51PS2*	VGN-A230B*	VGN-A215Z	VGN-A23CP			
	VGN-A51S1*	VGN-A230P*	VGN-A217M	VGN-A29CP			
	VGN-A51S2*	VGN-A240*	VGN-A217S	VGN-A29GP			
	VGN-A61B	VGN-A240B*	VGN-A295HP	VGN-A29LP			
	VGN-A71PS*	VGN-A240P*	VGN-A297XP	VGN-A29SP			
9-876-387-XX	VGN-A71S*	VGN-A250		VGN-A29TP			
		VGN-A260					
		VGN-A270*					
		VGN-A270B*					
		VGN-A270P*					
		VGN-A290					
		VGN-A290F					

*: CTO Model

: Additional Models

This manual and the constituent data may not be replicated, copied nor reprinted in whole or in part without prior written authorization of Sony Corporation.

本マニュアルの一部,または全部について,無断で データの複製、複写、転載することを禁じます。

> English/Japanese 2004L1600-1 © 2004 Sony Corporation Published by Sony EMCS VAIO-GSC [N]

Revision History

Suffix	Ver.	Date	Contents	QM No.
-01	Ver.1	2004.09.10	First Edition	
-02	Ver.2	2004.10.01	Front Page (Model Line Up), Page 3, Page 1-1_8, Page 3-1, Page 4-1, Page 4-3_7,	N2004_101AK
			Page 4-9_21, Page 4-23_32, Page 4-35, Page 5-3, Back Cover	
-03	Ver.3	2004.10.18	Front Page (Model Line Up), Page 3, Page 1-1_5, Page 4-1, Page 4-3, Page 4-5,	N2004_102AK
			Page 4-7, Page 4-9, Page 4-11, Page 4-13, Page 4-15, Page 4-17, Page 4-19_21,	
			Page 4-23, Page 4-25, Page 4-27, Page 4-31_35, Back Cover	
-04	Ver.4	2004.11.15	Front Page (Model Line Up), Page 3, Page 1-2, Page 4-1, Page 4-5, Page 4-7,	N2004_129AK
			Page 4-11, Page 4-13, Page 4-17, Page 4-19, Page 4-21, Page 4-29, Page 4-31_32,	
			Page 4-35, Back Cover	
-05	Ver.5	2004.12.13	Front Page (Model Line Up), Page 1-3, Page 3-2, Page 4-1, Page 4-3, Page 4-7,	N2004_131AK
			Page 4-9, Page 4-13, Page 4-15, Page 4-19, Page 4-21, Page 4-23, Page 4-31,	
			Page 4-32_4-35, Back Cover	
_	< Remar	ks >		